

# TECHNICAL MANUAL - MUTT MOTORCYCLES 125CC 125 EU5 M1 (MONOSHOCK VARIANTS) - V2.0/E2 08/21

## CONTENTS

125cc BIKE MODELS	125EU5M1-E05A
BIKE MODELS - PARTS GROUP IDENTIFICATION	125EU5M1-E06A28
125EU5M1-F01A	125EU5M1-E07A29
125EU5M1-F02A6	125EU5M1-E09A
125EU5M1-F03A	125EU5M1-E10A
125EU5M1-F04A8	125EU5M1-E11A32
125EU5M1-F05A9	125EU5M1-E12A
125EU5M1-F06A	125EU5M1-E13A34
125EU5M1-F06B	125EU5M1-E14A
125EU5M1-F07A	125EU5M1-E15A
125EU5M1-F08A	WIRING DIAGRAM
125EU5M1-F10A	TORQUE SETTINGS
125EU5M1-F10B	HANDOVER - PRE-DELIVERY INSPECTION CHECKLIST
125EU5M1-F11A	SERVICE INFORMATION - SERVICE SCHEDULE & GENERAL GUIDANCE 41
125EU5M1-F12A	SERVICE INFORMATION - FIRST SERVICE
125EU5M1-F12B	SERVICE INFORMATION - SECOND & THIRD SERVICE
125EU5M1-F13A	SERVICE INFORMATION - FOURTH & FIFTH SERVICE
125EU5M1-F13B20	SERVICE INFORMATION - SIXTH SERVICE ONWARDS
125EU5M1-F14A	TROUBLESHOOTING - GENERAL INFORMATION
125EU5M1-F15A	TROUBLESHOOTING - FAULT DIAGNOSIS - GENERAL
125EU5M1-E01A	TROUBLESHOOTING - FAULT DIAGNOSIS - FAULT CODES
125EU5M1-E02A	TROUBLESHOOTING - TESTING
125EU5M1-E03A25	
125EU5M1-E04A	



## 125cc BIKE MODELS

	BIKE MODEL	MODEL ID	DATE FROM
	Razorback 125-V2-Gloss Red	PM070GR	01/01/2021
O O			

<b>%</b> .	BIKE MODEL	MODEL ID	DATE FROM
- Aller	Razorback 125-V2-Matt Black	РМ070МВ	01/01/2021
0=0			

48-	BIKE MODEL	MODEL ID	DATE FROM
	Razorback 125-V2-Silver	PM070SV	01/01/2021
0-0			



## BIKE MODELS - PARTS GROUP IDENTIFICATION

		F01	F02	F03	F04	F05	F06	F07	F08	F10	F11	F12	F13	F14	F15
BIKE MODEL ID	BIKE MODEL ID NO.	TANK & SEAT	REAR FENDER & SIDE PANELS	ELECTRICS	ENGINE	HANDLEBARS	SWINGARM & REAR SHOCKS	FRONT FENDER & FRONT FORK	EXHAUST	FRAME	SPEEDOMETER & HEADLIGHT	WHEELS - FRONT	WHEELS - REAR	BRAKES	CABLES, MIRRORS, TOOLS
Razorback 125-V2-Gloss Red	PM070GR	F01A	F02A	F03A	F04A	F05A	F06A/F06B	F07A	F08A	F10A/F10B	F11A	F12B	F13B	F14A	F15A
Razorback 125-V2-Matt Black	PM070MB	F01A	F02A	F03A	F04A	F05A	F06A/F06B	F07A	F08A	F10A/F10B	F11A	F12A	F13A	F14A	F15A
Razorback 125-V2-Silver	PM070SV	F01A	F02A	F03A	F04A	F05A	F06A/F06B	F07A	F08A	F10A/F10B	F11A	F12B	F13B	F14A	F15A



## 125EU5M1-F01A

ENGINE	12	25	APPROVAL	EU5	VERSION	M1
DIAGRAM R	EF.	GROU	JP REF.	GROUP		
F01A		F01		TANK & SE	AT	
		-5		$ \begin{array}{c}                                     $		-15 -18 -17 -17 -17 -19 -19 -19

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1282	1241400520000	TANK - MONOSHOCK - MATT BLACK - EU5	C194	TANK		Matt Black	1
1	MPT-1283	1241400620000	TANK - MONOSHOCK - GLOSS RED - EU5	C194	TANK		Gloss Red	1
1	MPT-1284	1241400720000	TANK - MONOSHOCK - SILVER - EU5	C194	TANK		Silver	1
2	MPT-0381	1260300010000	RUBBER - FUEL TANK - FRONT	C144	RUBBER		No Colour	2
3	MPT-1065	1180400149100	FUEL SENSOR	C159	SENSOR		No Colour	1
4	MPT-0962	7643106016170	HEX SHOULDER BOLT - FLANGED - M6×20	C012	BOLT	M6×20(ø8×4.8)	No Colour	2
5	MPT-1061	1181400169000	LOCK SET	C110	LOCK SET		No Colour	1
6	MPT-1285	1114500012000	FUEL PUMP - MONOSHOCK - 350KPA	C086	FUEL PUMP		No Colour	1
7	MPT-0029	1040300142000	SEALING WASHER - FUEL PUMP	C156	SEALING WASHER	M6	No Colour	5
8	MPT-0820	7012805020154	BOLT - M5×20	C012	BOLT	M5×20	No Colour	5
9	MPT-1069	1114111023000	HIGH PRESSURE FUEL HOSE - 120MM	C098	HIGH PRESSURE FUEL HOSE	120mm	No Colour	1
10	MPT-0815	7012406040268	HEX BOLT - M6×40 - TANK	C012	BOLT	M6×40	No Colour	2
11	MPT-0922	7052706222038	WASHER - 6×22×2 - TANK	C206	WASHER	6×22×2	No Colour	2
12	MPT-0425	1261700020000	RUBBER RING - TANK	C149	RUBBER RING		No Colour	2
13	MPT-0426	1261700050000	T-RUBBER - TANK	C191	T-RUBBER	19mm	No Colour	1
14	MPT-0398	1260300450000	BUSHING	C023	BUSHING	ø8×ø10×25	No Colour	2
15	MPT-1044	1211400040000	SEAT - FLAT BLACK	C157	SEAT		Black	1
16	MPT-0915	7050108161648	WASHER - FLAT - 8×16×1.6	C206	WASHER	8×16×1.6	No Colour	1
17	MPT-0379	1260200200000	BOLT - M8×100	C012	BOLT	M8×100	No Colour	1
18	MPT-1070	1260300300000	RUBBER RING - TORSION BAR	C149	RUBBER RING		No Colour	1
19	MPT-1071	7013008035169	BOLT - M8×35	C012	BOLT	M8×35	No Colour	1
20	MPT-0033	1040300370000	TOOL KIT	C200	TOOL KIT		No Colour	1
21	MPT-1072	1261800081000	TOOLS STRAP	C213	STRAP	L=70mm	No Colour	1

6	<b>MUTT</b> Motorcycles
---	----------------------------

## 125EU5M1-F02A


ENGINE	125		125 APPROVAL EU		VERSION	M1
DIAGRAM R	IAGRAM REF. GROUP REF.					
F02A		F02		REAR FEND	ER & SIDE PA	ANELS
			34 33 32 4			
			•	15	16	
			29	17-0	18 11 1 1 Ø <sup>2</sup> <sup>6</sup> -39	
	2	22	23	2 1 8 12	5 11 6 9 9	0
25	ę ę		Total 7	E A B	11	18 17     @n @
			ALL ALL			2 Million
35-‡‡-3	6 26	2	20 19		1 34 1	4 13
L.	24	21	20 <sup>19</sup> 28	55	37	38

						G	Motorcy	<b>T</b> cles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1053	1171400091000	TAIL LIGHT - BLACK	C193	TAIL LIGHT		Black	1
2	MPT-1013	1041400590000	BRACKET - REAR LIGHT	C015	BRACKET		No Colour	1
3	MPT-1073	7021805016153	SCREW - M5×16	C152	SCREW I	M5×16	No Colour	3
4	MPT-1018	1041400622000	FENDER - REAR - BLACK	C135	REAR FENDER		Black	1
4	MPT-1019	1041400620000	FENDER - REAR - BRUSHED	C135	REAR FENDER		Brushed Aluminium	1
5	MPT-1054	1171801006000	LICENCE PLATE LIGHT	C212	LIGHT		No Colour	1
6	MPT-1074	1041400723000	TAIL COVER	C054	COVER		No Colour	1
7	MPT-1012	1041400722000	BRACKET - FENDER - REAR - LONG	C015	BRACKET		No Colour	1
8	MPT-0949	7513706012260	LARGE HEXAGONAL FLAT HEAD SCREW - M6×12	C152	SCREW I	M6×12	No Colour	1
9	MPT-0856	7013006016179	HEX BOLT - FLANGED - M6×16	C012	BOLT	M6×16	No Colour	2
10	MPT-0905	7032606000248	HEX NUT - FLANGED - M6	C118	NUT	M6	No Colour	7
11	MPT-1055	1261400942000	REFLECTOR - REAR	C137	REFLECTOR		No Colour	1
12	MPT-0428	1263200090000	ROUND RUBBER PAD	C148	RUBBER PAD		No Colour	1
13	MPT-1051	1171400042000	INDICATOR - REAR - LH	C102	INDICATOR		Black	1
14	MPT-1002	1041000223000	BRACKET - INDICATOR - REAR - LH	C015	BRACKET		No Colour	1
15	MPT-1052	1171400043000	INDICATOR - REAR - RH	C102	INDICATOR		Black	1
16	MPT-1003	1041000224000	BRACKET - INDICATOR - REAR - RH	C015	BRACKET		No Colour	1
17	MPT-0921	7050312242538	WASHER - 12×24×2.5	C206	WASHER 1	12×24×2.5	No Colour	2
18	MPT-0422	1261400141000	RUBBER SLEEVE - INDICATORS	C151	RUBBER SLEEVE		No Colour	2
19	MPT-0860	7013006025169	HEX BOLT - FLANGED - M6×25	C012	BOLT	M6×25	No Colour	3
20	MPT-0382	1260300060000	BATTERY BUSH BRACE - SMALL	C022	BUSH BRACE	SMALL	No Colour	3
21	MPT-0384	1260300070000	RUBBER GROMMET - BATTERY	C146	RUBBER GROMMET	ø9×ø13×20×8.8mm	No Colour	3
22	MPT-0855	7013006012268	HEX BOLT - FLANGED - M6×12	C012	BOLT	M6×12	No Colour	4
23	MPT-1035	1220300144000	FENDER - FRONT - PLASTIC	C082	FRONT FENDER		No Colour	1
24	MPT-1041	1251400061000	SIDE PANEL - BLACK - LH	C161	SIDE PANEL		Matt Black	1
24	MPT-1043	1251400060000	SIDE PANEL - SILVER - RH	C161	SIDE PANEL		Silver	1
25	MPT-1040	1251400051000	SIDE PANEL - BLACK - RH	C161	SIDE PANEL		Matt Black	1
25	MPT-1042	1251400050000	SIDE PANEL - SILVER - LH	C161	SIDE PANEL		Silver	1
26	MPT-1075	1261800082000	BATTERY STRAP	C213	STRAP 1	120mm	No Colour	1
27	MPT-1076	1690400220000	SPONGE PAD - BATTERY	C214	SPONGE PAD 7	70×50×10	No Colour	1
28	MPT-1058	1150000046000	BATTERY - 3AH	C009	BATTERY		No Colour	1
29	MPT-1077	1260300130100	FAIRING STRIP - 200MM	C215	FAIRING STRIP	200mm	No Colour	2
30	MPT-1078	1260300430000	FAIRING STRIP - 250MM	C215	FAIRING STRIP	250mm	No Colour	2
31	MPT-1020	1041400127100	GRABRAIL - SIDE - LH	C007	GRABRAIL		Black	1
32	MPT-1021	1041400127200	GRABRAIL - SIDE - RH	C007	GRABRAIL		Black	1
33	MPT-0890	7024908025268	HEX SOCKET HEAD SCREW - M8×25	C152	SCREW I	M8×25	No Colour	2
34	MPT-0891	7024908035268	HEX SOCKET HEAD SCREW - M8×35	C152	SCREW I	M8×35	No Colour	2
35	MPT-0949	7513706012260	LARGE HEXAGONAL FLAT HEAD SCREW - M6×12	C152	SCREW I	M6×12	No Colour	2
36	MPT-1079	7513706012160	SCREW - M6×12	C152	SCREW 1	M6×12	No Colour	2
37	MPT-1080	1041400722100	BRACKET - FENDER - REAR - BLACK	C015	BRACKET		Black	1
38	MPT-1011	1041400721000	BRACKET - LICENCE PLATE	C015	BRACKET		No Colour	1
39	MPT-1081	7032605000138	NUT - M5	C118	TUN	M5	No Colour	3

#### 125EU5M1-F03A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM R	EF.	GROU	JP REF.	GROUP		
F03A				ELECTRICS		

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0306	1181000060100	HORN	C099	HORN		No Colour	1
2	MPT-0855	7013006012268	HEX BOLT - FLANGED - M6×12	C012	BOLT	M6×12	No Colour	1
3	MPT-1265	1180400932000	WIRING LOOM	C209	WIRING LOOM		No Colour	1
4	MPT-1057	1181400041000	REGULATOR/RECTIFIER	C138	REGULATOR/RECTIFIER		No Colour	1
5	MPT-0806	7011006020168	CROSS RECESSED HEX BOLT - M6×12	C012	BOLT	M6×12	No Colour	2
6	MPT-1010	1030100570000	BRACKET - REGULATOR	C015	BRACKET		No Colour	1
7	MPT-0862	7013006035268	HEX BOLT - FLANGED - M6×35	C012	BOLT	M6×35	No Colour	1
8	MPT-0296	1180300018100	IGNITION COIL - WITHOUT CABLE	C101	IGNITOR		No Colour	1
9	MPT-0310	1181400060000	INDICATOR RELAY - LED - 12V	C139	RELAY		No Colour	1
10	MPT-0307	1181400001000	FUEL PUMP RELAY	C139	RELAY		No Colour	3
11	MPT-1056	1183200030000	STARTER RELAY	C181	STARTER RELAY		No Colour	1
12	MPT-1082	7070039010008	SCREW - ST3.9×10	C152	SCREW	ST3.9×10	No Colour	2
13	MPT-1239	1114200020000	ECU - 125	C070	ECU		No Colour	1
14	MPT-1083	7013006012168	BOLT - M6×12	C012	BOLT	M6×12	No Colour	2
15	MPT-0470	1650400002000	SPARK PLUG CAP - NGK	C168	SPARK PLUG		No Colour	1
16	MPT-0297	1180300018300	IGNITION COIL CABLE	C101	IGNITOR		No Colour	1




6	MUTT Motorcycles
	0

#### 125EU5M1-F04A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM REF. GROUP			JP REF.	GROUP		
F04A F04			ENGINE			

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1286	6102191414202	ENGINE - GS125 - BLACK	C072	ENGINE		Black	1
2	MPT-1066	25600QMN2000	GEAR LEVER - BLACK	C109	LEVER		Black	1
3	MPT-0181	1114111002000	CYLINDER WALL TEMPERATURE SENSOR	C159	SENSOR		No Colour	1
4	MPT-1062	6202040013100	FUEL INJECTOR ASSEMBLY	C085	FUEL INJECTOR ASSEMBLY		No Colour	1
5	MPT-0591	6260030067000	RUBBER HOOP (WITH CLAMPS)	C147	RUBBER HOOP		No Colour	1
6	MPT-1287	1114111006300	THROTTLE ASSEMBLY	C197	THROTTLE		No Colour	1
7	MPT-0488	6250001004002	SPROCKET COVER	C178	SPROCKET COVER		No Colour	1
8	MPT-0822	7012805025154	BOLT - M5×25	C012	BOLT	M5×25	No Colour	1
9	MPT-0826	7012805035154	BOLT - M5×35	C012	BOLT	M5×35	No Colour	2
10	MPT-0803	7011005010158	CROSS RECESSED HEX BOLT - M5×10	C012	BOLT	M5×10	No Colour	1
11	MPT-0858	7013006020268	HEX BOLT - FLANGED - M6×20	C012	BOLT	M6×20	No Colour	1
12	MPT-0584	6260030061000	SPACER - FUEL INJECTION - PLASTIC	C166	SPACER		No Colour	1
13	MPT-0585	6260030061001	O-RING - FUEL INJECTION - BLACK RUBBER	C119	O-RING		Black	1
14	MPT-0492	6260010020001	OIL FILLER CAP - CNC - BLACK	C121	OIL FILLER CAP		Black	1
15	MPT-0765	6261025080000	ENGINE VALVE COVER - CNC - BLACK	C204	VALVE COVER		Black	2
16	MPT-0630	6260050090000	CLUTCH ARM	C046	CLUTCH ARM		No Colour	1
17	MPT-0946	7512406010164	SCREW - M6×16	C152	SCREW	M6×16	Chrome	1
18	MPT-0812	7012406020268	BOLT - M6×20	C012	BOLT	M6×25	No Colour	




B	MUTT Motorcycles
	8

#### 125EU5M1-F05A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM R	EF.	GROL	JP REF.	GROUP		
F05A F05				HANDLEBAR	?S	

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0239	1130100080200	HANDLEBAR - MUTT - BLACK	C095	HANDLEBAR	730mm,ø22mm	Matt Black	1
2	MPT-0976	1100400054100	HANDLEBAR MOUNT - TOP - BLACK	C117	MOUNT		Black	2
2	MPT-0978	1100400055100	HANDLEBAR MOUNT - SILVER - TOP	C117	MOUNT		Silver	2
3	MPT-0841	7012808035168	HEX BOLT - FLANGED - BLUE WHITE ZINC	C012	BOLT	M5×35	No Colour	4
4	MPT-0300	1180300123000	SWITCHGEAR - LH	C219	SWITCHGEAR		No Colour	1
5	MPT-0301	1180300233000	SWITCHGEAR - RH	C219	SWITCHGEAR		No Colour	1
6	MPT-0295	1180200115100	CLUTCH LEVER ASSEMBLY	C109	LEVER		Black	1
7	MPT-0415	1261400033000	GRIP - LEFT BAR - BLACK	C092	GRIP		Black	1
8	MPT-0418	1261400045000	GRIP - RIGHT BAR - BLACK	C092	GRIP		Black	1
9	MPT-0245	1139900016000	HANDLEBAR END - MUTT-R - BLACK	C096	HANDLEBAR END		Black	2
10	MPT-0377	1260200010000	CLUTCH CABLE SHEATH	C048	CLUTCH CABLE SHEATH		No Colour	1
11	MPT-0295	1180200115100	CLUTCH LEVER ASSEMBLY	C109	LEVER		Black	1
12	MPT-0377	1260200010000	CLUTCH CABLE SHEATH	C048	CLUTCH CABLE SHEATH		No Colour	1



B	MUTT Motorcycles
	0

#### 125EU5M1-F06A


ENGINE	125	APPROVAL	EU5	VERSION	M1	ITEM NO.	MUTT PART NO.	BARCOL
			1			1	MPT-0987	1041400
	0.001		000110			2	MPT-0988	1080100
DIAGRAM REF.	GROU	JP REF.	GROUP			3	MPT-1084	1041400
F06A	500					4	MPT-1085	1041400
-06A	F06		SWINGARM	& REAR SHO	JUKS	5	MPT-1086	1041400
						6	MPT-1087	1041400
						7	MPT-1088	1041400
						8	MPT-1089	1041400
						9	MPT-1090	1041400
						10	MPT-1091	1041400
						11	MPT-0989	1260300
						12	MPT-0856	7013006
				22 23 24		13	MPT-0990	1041400
				00	00021	14	MPT-0991	1041400
					and a comment	15	MPT-0992	1041400
						15	MPT-0994	1041400
						16	MPT-0993	1041400
			17			16	MPT-0995	1041400
				22		17	MPT-0996	1040300
			/H 13	000		18	MPT-1092	1041400
				- 6 26 27 OO	25	19	MPT-1093	7050108
				27 26		20	MPT-0999	1100300
		12 11		9	A	21	MPT-1094	7012810
			a e	200		22	MPT-1095	7034210
				1001		23	MPT-1096	1100300
				31 14		24	MPT-1097	1100300
~ <b>``O</b> `	7					25	MPT-1127	7013010
		15 2		6 3		26	MPT-1098	1100300
	00	EN THE	2 × K	30		27	MPT-1099	1100300
	00		18 2 0	15 9		28	MPT-1100	7513706
	~ <	0 000		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		29	MPT-1101	7021805
				28		30	MPT-0949	7513706

						G	Mut Motorcy	<b>T</b> vcles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0987	1041400140100	SWINGARM - REAR - COMPLETE	C187	SWINGARM		No Colour	1
2	MPT-0988	1080100143000	SWINGARM SHAFT PIVOT	C188	SWINGARM SHAFT	ø14×M14×1.5(23)×230	No Colour	1
3	MPT-1084	1041400140130	REAR FORK RETAINER	C216	RETAINER		No Colour	2
4	MPT-1085	1041400140140	THRUST RING	C142	RING		No Colour	2
5	MPT-1086	1041400140120	INNER BUSHING	C023	BUSHING		No Colour	2
6	MPT-1087	1041400140150	OIL SEAL	C124	OIL SEAL		No Colour	4
7	MPT-1088	1041400140110	SWINGARM - NEEDLE ROLLER BEARINGS	C011	BEARING		No Colour	2
8	MPT-1089	1041400140160	OIL SEAL	C124	OIL SEAL		No Colour	4
9	MPT-1090	1041400140170	INNER BUSHING	C023	BUSHING		No Colour	2
10	MPT-1091	1041400140180	SWINGARM - NEEDLE ROLLER BEARINGS	C011	BEARING		No Colour	2
11	MPT-0989	1260300292001	CHAIN SLIDER	C039	CHAIN SLIDER		No Colour	1
12	MPT-0856	7013006016179	HEX BOLT - FLANGED - M6×16	C012	BOLT	M6×16	No Colour	2
13	MPT-0990	1041400700000	CHAIN ADJUSTER - RH	C037	CHAIN ADJUSTER		No Colour	1
14	MPT-0991	1041400600000	CHAIN ADJUSTER - LH	C037	CHAIN ADJUSTER		No Colour	1
15	MPT-0992	1041400074510	BRACKET - CHAIN GUARD - REAR - BLACK	C015	BRACKET		Black	1
15	MPT-0994	1041400074500	BRACKET - CHAIN GUARD - REAR - BRUSHED	C015	BRACKET		Brushed Aluminium	1
16	MPT-0993	1041400074610	CHAIN GUARD - BLACK	C038	CHAIN GUARD		Black	1
16	MPT-0995	1041400074600	CHAIN GUARD - BRUSHED	C038	CHAIN GUARD		Brushed Aluminium	1
17	MPT-0996	1040300121000	FENDER - REAR - SMALL (PLASTIC)	C074	FENDER		No Colour	1
18	MPT-1092	1041400074700	REAR BRAKE CABLE CLAMP	C041	CLAMP		No Colour	2
19	MPT-1093	7050108161639	WASHER - ø12×ø6×1.5	C206	WASHER	ø12×ø6×1.5	No Colour	2
20	MPT-0999	1100300053200	SHOCK - REAR - 345MM - BLACK	C136	REAR SHOCK	345mm	Black	1
21	MPT-1094	7012810060268	BOLT - M10×60×1.25	C012	BOLT	M10×60×1.25	No Colour	1
22	MPT-1095	7034210000248	NUT - M10×1.25	C118	NUT	M10×1.25	No Colour	2
23	MPT-1096	1100300053201	BEARING BUSHING - T	C023	BUSHING		No Colour	2
24	MPT-1097	1100300053203	RUBBER BUSHING	C023	BUSHING		No Colour	2
25	MPT-1127	7013010050168	BOLT - M10×50×1.25	C012	BOLT	M10×50×1.25	No Colour	1
26	MPT-1098	1100300053202	BEARING BUSHING - T - LOWER	C023	BUSHING		No Colour	2
27	MPT-1099	1100300053205	INNER BUSHING	C023	BUSHING		No Colour	2
28	MPT-1100	7513706008260	SCREW - M6×8	C152	SCREW	M6×8	No Colour	1
29	MPT-1101	7021805012158	SCREW - M5×12	C152	SCREW	M5×12	No Colour	2
30	MPT-0949	7513706012260	LARGE HEXAGONAL FLAT HEAD SCREW - M6×12	C152	SCREW	M6×12	No Colour	3
31	MPT-0905	7032606000248	HEX NUT - FLANGED - M6	C118	NUT	M6	No Colour	2

#### 125EU5M1-F06B

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM REF. GROUP REF.				GROUP		
F06B F06			SWINGARM	& REAR SHC	OCKS	

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1102	1083700190400	SWINGARM SPINDLE - REAR	C173	SPINDLE		No Colour	1
2	MPT-1103	7050314382539	WASHER - 14×38×2.5	C206	WASHER	14×38×2.5	No Colour	2
3	MPT-1104	6260030029300	OIL SEAL	C124	OIL SEAL		No Colour	2
4	MPT-1105	6260030029200	BUSHING	C023	BUSHING	ø14×ø38×36	No Colour	1
5	MPT-1106	1083700190000	ROCKER ARM - SHOCK - REAR	C217	ROCKER ARM		No Colour	1
6	MPT-1107	1083700190300	NEEDLE ROLLER BEARINGS	C011	BEARING		No Colour	1
7	MPT-1108	7034214000248	NUT - M14×1.5	C118	NUT	M14×1.5	No Colour	1
8	MPT-1109	7013012060268	BOLT - M12×60×1.25	C012	BOLT	M12×60×1.25	No Colour	1
9	MPT-1110	1083700190500	BEARING BUSHING - T	C023	BUSHING		No Colour	2
10	MPT-1111	1083700190510	BEARING BUSHING DUST WASHER	C206	WASHER		No Colour	2
11	MPT-1112	1083700190520	ELASTIC COLLAR	C050	COLLAR		No Colour	2
12	MPT-1113	1083700190530	KNUCKLE BEARINGS	C011	BEARING		No Colour	1
13	MPT-1114	7034212000248	NUT - M12×1.25	C118	NUT	M12×1.25	No Colour	1



6	MUTT Metorcycles
	1

#### 125EU5M1-F07A

ENGINE	125	APPROVAL	EU5	VERSION	M1	ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGOR
					<b>_</b> ]	1	MPT-1007	1041400612000	FENDER - FRONT - BLACK	C082	FRONT FEI
						1	MPT-1008	1041400610000	FENDER - FRONT - BRUSHED	C082	FRONT FE
DIAGRAM REF	. GRO	OUP REF.	GROUP			2	MPT-0905	7032606000248	HEX NUT - FLANGED - M6	C118	NUT
						3	MPT-1006	1041400580000	BRACKET - FENDER - FRONT	C015	BRACKET
F07A	F07		FRONT FE	NDER & FRON	IT FORK	4	MPT-0856	7013006016179	HEX BOLT - FLANGED - M6×16	C012	BOLT
L	I		1			5	MPT-0983	1101400012300	FRONT FORK - WITH CNC BLACK CAP - LH - BLACK	C083	FRONT FO
						5	MPT-0985	1101400012400	FRONT FORK - WITH CNC BLACK CAP - LH - GOLD	C083	FRONT FO
						5	MPT-1115	1101400012500	FRONT FORK - WITH CNC SILVER CAP - LH - BLACK	C077	FORK
						6	MPT-0984	1101400022300	FRONT FORK - WITH CNC BLACK CAP - RH - BLACK	C083	FRONT FO
						6	MPT-0986	1101400022400	FRONT FORK - WITH CNC BLACK CAP - RH - GOLD	C083	FRONT FO
						6	MPT-1116	1101400022500	FRONT FORK - WITH CNC SILVER CAP - RH - BLACK	C077	FORK
						7	MPT-0397	1260300410000	SPEEDOMETER CABLE CLAMP	C041	CLAMP
			6	Q −24		8	MPT-1118	1030100500000	BRAKE HOSE CLAMP	C041	CLAMP
				28		9	MPT-1119	1030100580000	BRAKE HOSE CLAMP - LOWER LH	C041	CLAMP
				€ U U	17	10	MPT-1120	7012806012169	BOLT - M6×12	C012	BOLT
			$\Box$	S−19	11 10	11	MPT-1121	1030100502000	FUEL HOSE SLEEVE	C165	SLEEVE
				-20	je je ze	12	MPT-0888	7024908020267	HEX SOCKET HEAD SCREW - M8×20	C012	BOLT
		18		-21	$\bigcirc$	13	MPT-1122	7022005008161	SCREW - M5×8	C152	SCREW
			-25	-22		14	MPT-1123	7032605000161	NUT - M5	C118	NUT
				$\square$		15	MPT-1124	7022005025161	SCREW - M5×25	C152	SCREW
		29(E	5)	/ /		16	MPT-1125	1030100503000	BRACKET SLEEVE (ABS)	C165	SLEEVE
	16	6-/ / 3	3-7- 6	• / /		17	MPT-1126	1030100501000	BRAKE HOSE CLAMP - LH	C041	CLAMP
	_			14	15 13	18	MPT-1142	7013008045168	BOLT - M8×45	C012	BOLT
	F			-5	9 ~9 ~9 ~9 1	19	MPT-0118	1051400090000	HEADSTOCK DUST SEAL	C069	DUST SEA
	7				a_0_08_0	20	MPT-0117	1051400060000	HEADSTOCK COLLAR	C050	COLLAR
	Ć		$\sim$		16	21	MPT-0119	1051400130000	HEADSTOCK TOP BEARING	C011	BEARING
	7(E5)- 💊			8		22	MPT-0120	1051400140000	HEADSTOCK LOWER BEARING	C011	BEARING
	9					23	MPT-0916	7050122361034	WASHER - FLAT - 22.5×36×1.0	C206	WASHER
	30(E5)-	/ /				24	MPT-0980	1050100052100	HEADSTEM CAP NUT - CNC - BLACK - M22×1.25	C034	CAP NUT
	31(E5)-000 /		/	2		24	MPT-0982	1050100052200	HEADSTEM CAP NUT - CNC - BRUSH - M22×1.25	C034	CAP NUT
	12-0-	1	•	Ø 4		25	MPT-0979	1100400053000	YOKE - BOTTOM - BLACK	C210	YOKE
	12- <b>6</b>	Ĵ.	4 5	10 ° ° ° °		25	MPT-0981	1100400057000	YOKE - BOTTOM - SILVER	C210	YOKE
			- C			26	MPT-1127	7013010050168	BOLT - M10×50×1.25	C012	BOLT
			8			27	MPT-0975	1100400054000	YOKE - TOP - BLACK	C210	YOKE
						27	MPT-0977	1100400056000	YOKE - TOP - SILVER	C210	YOKE
						28	MPT-0949	7513706012260	LARGE HEXAGONAL FLAT HEAD SCREW - M6×12	C152	SCREW
						29	MPT-0397	1260300330000	CLAMP	C041	CLAMP
											T

30

31

MPT-1264

MPT-1288

1030100491000 SPEEDOMETER CABLE LIMIT CLAMP

7021805012159 SCREW - M5×12

C041


C152

		6	Motorcy	<b>f</b> cles
E	CATEGORY	SIZE	COLOUR	QTY.
	FRONT FENDER		Black	1
	FRONT FENDER		Brushed Aluminium	1
	NUT	M6	No Colour	2
	BRACKET		No Colour	1
	BOLT	M6×16	No Colour	4
	FRONT FORK	820mm	Black	1
	FRONT FORK	820mm	Gold	1
	FORK	820mm	Black	1
	FRONT FORK	820mm	Black	1
	FRONT FORK	820mm	Gold	1
	FORK	820mm	Black	1
	CLAMP		No Colour	1
	CLAMP		No Colour	1
	CLAMP		No Colour	1
	BOLT	M6×12	No Colour	2
	SLEEVE		No Colour	1
	BOLT	M8×20	No Colour	1
	SCREW	M5×8	No Colour	4
	NUT	M5	No Colour	4
	SCREW	M5×25	No Colour	4
	SLEEVE		No Colour	2
	CLAMP		No Colour	1
	BOLT	M8×45	No Colour	4
	DUST SEAL		No Colour	1
	COLLAR		No Colour	1
	BEARING		No Colour	1
	BEARING		No Colour	1
	WASHER	22.5×36×1.0	No Colour	1
	CAP NUT	M22×1.25	Black	1
	CAP NUT	M22×1.25	Silver	1
	YOKE		Black	1
	YOKE		Silver	1
	BOLT	M10×50×1.25	No Colour	2
	YOKE		Black	1
	YOKE		Silver	1
	SCREW	M6×12	No Colour	2
	CLAMP		No Colour	1
	CLAMP		No Colour	1
	SCREW	M5×12	No Colour	2

#### 125EU5M1-F08A

ENGINE	12	25	APPROVAL	EU5	VERSION	M1
DIAGRAM REF.		GROL	JP REF.	GROUP		
F08A		F08		EXHAUST		

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY
1	MPT-1291	1121400059100	EXHAUST SYSTEM - COMPLETE - QUIET - BLACK (125 MONO-	C073	EXHAUST
1	MPT-1292	1121400058100	EXHAUST SYSTEM - COMPLETE - QUIET - BRUSHED (125 MONO-	C073	EXHAUST
2	MPT-0890	7024908025268	HEX SOCKET HEAD SCREW - M8×25	C152	SCREW
3	MPT-0463	1590300011000	EXHAUST GASKET	C088	GASKET
4	MPT-0914	7050008104235	WASHER - ELASTIC - 8×10.1×4.2	C071	ELASTIC WASHER
5	MPT-0852	7012810055268	HEX EYEBOLT - FLANGED - M10×55×1.25 - BRAKE PEDAL	C012	BOLT
6	MPT-1034	1221400024001	AIR CLEANER ASSEMBLY	C004	AIR CLEANER ASSEMB
7	MPT-0855	7013006012268	HEX BOLT - FLANGED - M6×12	C012	BOLT
8	MPT-0180	1114111001000	OXYGEN SENSOR	C159	SENSOR
9	MPT-0110	1041701120000	BRACKET - CARBON CANISTER	C015	BRACKET
10	MPT-1293	1041701160000	CONNECTING PLATE - CARBON CANISTER BRACKET	C222	CONNECTING PLATE
11	MPT-1294	6301075000004	HEX NUT - FLANGED - M6	C118	NUT
12	MPT-0406	1260300981000	CLAMP - FUEL HOSE	C041	CLAMP
13	MPT-0407	1260300982000	CLAMP - FUEL HOSE	C041	CLAMP
14	MPT-1295	1260400900000	CARBON TANK TUBE	C079	TUBE
15	MPT-1296	1260400841600	TUBE	C079	TUBE
16	MPT-1297	1120302562000	CARBON CANISTER	C035	CARBON CANISTER



	G	Motorcy	<b>T</b> cles
GORY	SIZE	COLOUR	QTY.
UST		Black	1
UST		Brushed Aluminium	1
W	M8×25	No Colour	2
ET		No Colour	1
TIC WASHER	8×10.1×4.2	No Colour	2
	M10×55×1.25	No Colour	1
LEANER ASSEMBLY		No Colour	1

No Colour

3

1

1

1

2 З

1

1

1

1

M6×12

ø8.0×1

ø9.5×1

ø4.7×ø8.5×450

#### 125EU5M1-F10A


ENGINE	12	25	APPROVAL	EU5	VERSION	M1
	EF.	GROU	JP REF.	GROUP		
F10A		F10		FRAME		
				18	22 21 20 20 20 20 20 20 20 20 20 20	
1		S			17 15	
			POS A		0	19 20 30 30
					16	S® 21   20
33-00 000 CE 9				8 10-	12 14 7 7 14 7 7 14 13	24
**************************************		32 29 () 32 31	29		13	26

						B	<b>MUT</b> Motorcy	<b>T</b> icles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0969	1031400100000	FRAME - 125 - MONOSHOCK	C080	FRAME		Black	1
2	MPT-0014	1030300030000	ENGINE BRACKET - UPPER	C015	BRACKET		No Colour	2
3	MPT-0869	7013008050168	HEX BOLT - FLANGED - M8×50	C012	BOLT	M8×50	No Colour	3
4	MPT-0907	7033608000148	SELF-LOCKING HEX NUT - FLANGED - M8	C158	SELF-LOCKING NUT	M8	No Colour	8
5	MPT-0013	1030300029000	ENGINE BRACKET - LOWER	C015	BRACKET		No Colour	1
6	MPT-1022	1041400071101	FOOTPEG - FRONT- LH	C076	FOOTPEG		Black	1
7	MPT-1023	1041400071102	FOOTPEG - FRONT- RH	C076	FOOTPEG		Black	1
8	MPT-0877	7013012035269	HEX BOLT - FLANGED - M12×35×1.25	C012	BOLT	M12×35×1.25	No Colour	2
9	MPT-0971	1041400060001	SIDE STAND - 310MM	C162	SIDE STAND		No Colour	1
10	MPT-0972	1290300111000	SIDE STAND SPRING	C176	SPRING		No Colour	1
11	MPT-0960	7640310035167	SIDE STAND BOLT - M10×35×1.5	C012	BOLT	M10×35×1.5	No Colour	1
12	MPT-0898	7031910000147	HEX NUT - M10×1.5	C118	NUT	M10×1.5	No Colour	1
13	MPT-0314	1183700220000	SIDE STAND SWITCH	C189	SWITCH		No Colour	1
14	MPT-0880	7021805014157	SCREW - M5×14	C152	SCREW	M5×14	No Colour	2
15	MPT-1016	1041400074400	BRACKET - FOOTPEG - REAR - LH	C015	BRACKET		No Colour	1
16	MPT-1133	7012808216168	BOLT - M8×16	C012	BOLT	M8×16	No Colour	2
17	MPT-1017	1041400074300	BRACKET - FOOTPEG - REAR - RH	C015	BRACKET		No Colour	1
18	MPT-1134	7012808220168	BOLT - M8×16	C012	BOLT	M8×16	No Colour	2
19	MPT-1024	1041400074200	FOOTPEG - REAR - LH	C076	FOOTPEG		Black	1
20	MPT-1135	7012810020268	BOLT - M10×20×1.25	C012	BOLT	M10×20×1.25	No Colour	2
21	MPT-1136	7034310000248	NUT - M10×1.25	C118	NUT	M10×1.25	No Colour	2
22	MPT-1025	1041400084200	FOOTPEG - REAR - RH	C076	FOOTPEG		Black	1
23	MPT-1014	1250809000503	MASTER CYLINDER HEAL GUARD - REAR - BLACK	C115	MASTER CYLINDER REAR COVER		Black	1
23	MPT-1137	1250809000403	MASTER CYLINDER HEAL GUARD - REAR - BRUSHED	C093	GUARD		Brushed Aluminium	1
24	MPT-0949	7513706012260	LARGE HEXAGONAL FLAT HEAD SCREW - M6×12	C152	SCREW	M6×12	No Colour	5
25	MPT-1015	1030100560000	BRACKET - CBS	C015	BRACKET		No Colour	1
26	MPT-1138	7513706016260	SCREW - M6×16	C152	SCREW	M6×16	No Colour	4
28	MPT-1139	1260300292002	CHAIN RUBBER	C144	RUBBER		No Colour	1
29	MPT-1140	1031400102000	BUFFER SLEEVE	C165	SLEEVE		No Colour	2
30	MPT-1141	7012808120163	BOLT - M8×120	C012	BOLT	M8×120	No Colour	1
31	MPT-0870	7013008065168	HEX BOLT - FLANGED - M8×65	C012	BOLT	M8×65	No Colour	2
32	MPT-0872	7013008080168	HEX BOLT - FLANGED - M8×80	C012	BOLT	M8×80	No Colour	1
33	MPT-0396	1260300330000	CLAMP - CLUTCH CABLE	C041	CLAMP	ø8.5×17×75	No Colour	1

#### 125EU5M1-F10B

ENGINE	12	25	APPROVAL	EU5	VERSION	M1
DIAGRAM REF.		GROL	JP REF.	GROUP		
F10B		F10		FRAME		

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0362	1250809000800	SUMP GUARD - 125 - BLACK	C186	SUMP GUARD		Black	1
1	MPT-0361	1250809000700	SUMP GUARD - 125 - BRUSHED	C186	SUMP GUARD		Brushed Aluminium	1
2	MPT-0025	1040101200000	BRACKET - SUMP GUARD - MAIN	C015	BRACKET		Black	1
3	MPT-0970	1030100045000	BRACKET - BRAKE CALIPER - FRONT	C015	BRACKET		No Colour	2
4	MPT-0920	7050310202038	WASHER - 10×20×2 - FRONT CALIPER	C206	WASHER	10×20×2	No Colour	4
5	MPT-1135	7012810020268	BOLT - M10×20×1.25	C012	BOLT	M10×20×1.25	No Colour	3
6	MPT-0852	7012810055268	HEX EYEBOLT - FLANGED - M10×55×1.25 - BRAKE PEDAL	C012	BOLT	M10×55×1.25	No Colour	1
7	MPT-0843	7012808036168	HEX BOLT - FLANGED - M8×20	C012	BOLT	M8×20	No Colour	2
8	MPT-1142	7013008045168	BOLT - M8×45	C012	BOLT	M8×45	No Colour	1
9	MPT-0874	7013008090168	HEX BOLT - FLANGED - M8×90	C012	BOLT	M8×90	No Colour	1






## 125EU5M1-F11A

ENGINE	NE 125		APPROVAL	EU5	EU5 VERSION		
DIAGRAM REF.		GROL	JP REF.	GROUP			
F11A		F11		SPEEDOMETER & HEADLIGHT			

	ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
	1	MPT-1251	1161400016700	SPEEDOMETER - DIGITAL - BLACK	C172	SPEEDOMETER		Black	1
	2	MPT-1009	1100400054200	SPEEDOMETER SURROUND - BLACK	C171	SPEEDO SURROUND		Black	1
	2	MPT-1128	1100400054300	SPEEDOMETER SURROUND - SILVER	C171	SPEEDO SURROUND		Silver	1
	3	MPT-0905	7032606000248	NUT - M6	C118	NUT	M6	No Colour	2
	4	MPT-1130	7513706016160	SCREW - M6×16	C152	SCREW	M6×16	No Colour	1
_	5	MPT-1131	7513706020160	SCREW - M6×20	C152	SCREW	M6×20	No Colour	1
	6	MPT-1061	1181400169000	LOCK SET	C110	LOCK SET		No Colour	1
	7	MPT-0887	7024906016260	HEX SOCKET HEAD SCREW - M6×16	C012	BOLT	M6×16	No Colour	2
	8	MPT-1049	1171400032000	INDICATOR - FRONT - LH	C102	INDICATOR		Black	1
	9	MPT-1050	1171400033000	INDICATOR - FRONT - RH	C102	INDICATOR		Black	1
	10	MPT-1000	1030100520000	BRACKET - INDICATOR - FRONT - LH	C015	BRACKET		No Colour	1
	11	MPT-1001	1030100510000	BRACKET - INDICATOR - FRONT - RH	C015	BRACKET		No Colour	1
	12	MPT-1132	7021805008158	BOLT - M5×8	C012	BOLT	M5×8	No Colour	2
	13	MPT-0422	1261400141000	RUBBER SLEEVE - INDICATORS	C151	RUBBER SLEEVE		No Colour	2
	14	MPT-0424	1261400943000	REFLECTOR - FRONT	C137	REFLECTOR		No Colour	2
	15	MPT-1005	1030100540000	BRACKET - REFLECTOR - FRONT - LH	C015	BRACKET		No Colour	1
	16	MPT-1004	1030100530000	BRACKET - REFLECTOR - FRONT - RH	C015	BRACKET		No Colour	1
	17	MPT-1048	1171000054000	HEADLIGHT - MATT BLACK	C097	HEADLIGHT		Black	1
	18	MPT-1070	1260300300000	RUBBER RING	C149	RUBBER RING		No Colour	2
	19	MPT-1263	1161400016704	WIRE - SPEEDOMETER	C208	WIRE		No Colour	1




G	Motorcy	<b>f</b> cles
SIZE	COLOUR	QTY.
	Black	1
	Black	1
	Cilver	1

#### 125EU5M1-F12A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM REF.		GROL	JP REF.	GROUP		
F12A		F12				

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0153	1090100215000	TYRE - 120/90×18 TIMSUN 65P	C202	TYRE	120/90×18	No Colour	1
2	MPT-0154	1090100216000	INNER TUBE - TIMSUN 120/90×18	C103	INNER TUBE	120/90×18	No Colour	1
3	MPT-1146	1090100999200	RIM TAPE	C141	RIM TAPE		No Colour	1
4	MPT-1270	1081400058000	SPEEDOMETER DRIVE - DIGITAL	C170	SPEEDO DRIVE		No Colour	1
5	MPT-0132	1081400014910	WHEEL - FRONT - ALL BLACK - STAINLESS SPOKES - ALUMINIUM RIM	C207	WHEEL	2.5×18 INCH	Black	1
6	MPT-1046	1141400029200	BRAKE DISC - FRONT	C062	DISC		No Colour	1
7	MPT-0845	7012808041168	STEP BOLT - M8×20 - DISC	C183	STEP BOLT	M8×20	No Colour	4
8	MPT-1026	1081400060906	WHEEL SPINDLE - FRONT	C173	SPINDLE		No Colour	1
9	MPT-1027	1081400070910	SPACER - FRONT WHEEL	C023	BUSHING		No Colour	1
	MPT-1357	1551400008700	WHEEL BEARING SEAL - FRONT - LH/RH	C153	SEAL	ø22×ø35×5	No Colour	2






#### 125EU5M1-F12B

ENGINE	125		APPROVAL	EU5	VERSION	M1			
DIAGRAM REF.		GROL	JP REF.	GROUP					
F12B	F12B F12 W				WHEELS - FRONT				

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1143	1090200041000	TYRE - 110/90-18 TIMSUN	C202	TYRE	110/90-18	No Colour	1
2	MPT-1144	1090100789200	INNER TUBE - TIMSUN 110/90-18	C103	INNER TUBE	110/90-18	No Colour	1
3	MPT-1146	1090100999200	RIM TAPE	C141	RIM TAPE		No Colour	1
4	MPT-1270	1081400058000	SPEEDOMETER DRIVE - DIGITAL	C170	SPEEDO DRIVE		No Colour	1
5	MPT-0132	1081400014910	WHEEL - FRONT - ALL BLACK - STAINLESS SPOKES - ALUMINIUM RIM	C207	WHEEL	2.5×18 INCH	Black	1
6	MPT-1046	1141400029200	BRAKE DISC - FRONT	C062	DISC		No Colour	1
7	MPT-0845	7012808041168	STEP BOLT - M8×20 - DISC	C183	STEP BOLT	M8×20	No Colour	4
8	MPT-1026	1081400060906	WHEEL SPINDLE - FRONT	C173	SPINDLE		No Colour	1
9	MPT-1027	1081400070910	SPACER - FRONT WHEEL	C023	BUSHING		No Colour	1
	MPT-1357	1551400008700	WHEEL BEARING SEAL - FRONT - LH/RH	C153	SEAL	ø22×ø35×5	No Colour	2






#### 125EU5M1-F13A

ENGINE	125		APPROVAL	EU5	VERSION	M1	
DIAGRAM REF.		GROL	JP REF.	GROUP			
F13A	F13A F13		WHEELS - REAR				

ITEM		BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0153	1090100215000	TYRE - 120/90×18 TIMSUN 65P	C202	TYRE	120/90×18	No Colour	1
2	MPT-0154	1090100216000	INNER TUBE - TIMSUN 120/90×18	C103	INNER TUBE	120/90×18	No Colour	1
3	MPT-1146	1090100999200	RIM TAPE	C141	RIM TAPE		No Colour	1
4	MPT-0135	1081400029100	WHEEL - REAR - ALL BLACK - STAINLESS SPOKES - ALUMINIUM RIM	C207	WHEEL	2.5×18 INCH	Black	1
5	MPT-1047	1141400029300	BRAKE DISC - REAR	C062	DISC		No Colour	1
6	MPT-0848	7012808225167	NUT - HEX FLAT HEAD STEP BOLT - M8×25 - DISC	C183	STEP BOLT	M8×25	No Colour	4
7	MPT-0998	1070100052000	SPROCKET - REAR - 428-46T	C177	SPROCKET	428,46T	No Colour	1
8	MPT-0932	7112210030268	BOLT WITH WASHER - M10×30×1.25 - SPROCKET REAR	C013	BOLT WITH WASHER	M10×30×1.25	No Colour	4
9	MPT-1029	1081400060916	WHEEL SPINDLE - REAR	C173	SPINDLE	M14 (ø15)×1.5 (25)×275	No Colour	1
10	MPT-1030	1081400070920	SPACER - REAR WHEEL - LH	C023	BUSHING		No Colour	1
11	MPT-1031	1081400070930	SPACER - REAR WHEEL - RH	C023	BUSHING	ø27×ø15×10.5	No Colour	1
12	MPT-0997	1070200150000	CHAIN - 428HG-132L	C036	CHAIN	428HG-132L	No Colour	1
	MPT-1172	1551400008500	WHEEL BEARING SEAL - REAR - RH	C153	SEAL	ø27×ø47×7	No Colour	1
	MPT-1173	1551400008600	WHEEL BEARING SEAL - REAR - LH	C153	SEAL	ø28×ø42×7	No Colour	1




6	<b>MUTT</b> Motorcycles

#### 125EU5M1-F13B

ENGINE	125		APPROVAL	EU5	VERSION	M1	
DIAGRAM REF. GR		GROL	JP REF.	GROUP			
F13B		F13		WHEELS - REAR			

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1145	1090120721000	TYRE - 130/80-18 TIMSUN 65P	C202	TYRE	130/80-18	No Colour	1
2	MPT-0156	1090100218000	INNER TUBE - TIMSUN 130/80×18	C103	INNER TUBE	130/80×18	No Colour	1
3	MPT-1146	1090100999200	RIM TAPE	C141	RIM TAPE		No Colour	1
4	MPT-0135	1081400029100	WHEEL - REAR - ALL BLACK - STAINLESS SPOKES - ALUMINIUM RIM	C207	WHEEL	2.5×18 INCH	Black	1
5	MPT-1047	1141400029300	BRAKE DISC - REAR	C062	DISC		No Colour	1
6	MPT-0848	7012808225167	NUT - HEX FLAT HEAD STEP BOLT - M8×25 - DISC	C183	STEP BOLT	M8×25	No Colour	4
7	MPT-0998	1070100052000	SPROCKET - REAR - 428-46T	C177	SPROCKET	428,46T	No Colour	1
8	MPT-0932	7112210030268	BOLT WITH WASHER - M10×30×1.25 - SPROCKET REAR	C013	BOLT WITH WASHER	M10×30×1.25	No Colour	4
9	MPT-1029	1081400060916	WHEEL SPINDLE - REAR	C173	SPINDLE	M14 (ø15)×1.5 (25)×275	No Colour	1
10	MPT-1030	1081400070920	SPACER - REAR WHEEL - LH	C023	BUSHING		No Colour	1
11	MPT-1031	1081400070930	SPACER - REAR WHEEL - RH	C023	BUSHING	ø27×ø15×10.5	No Colour	1
12	MPT-0997	1070200150000	CHAIN - 428HG-132L	C036	CHAIN	428HG-132L	No Colour	1
	MPT-1172	1551400008500	WHEEL BEARING SEAL - REAR - RH	C153	SEAL	ø27×ø47×7	No Colour	1
	MPT-1173	1551400008600	WHEEL BEARING SEAL - REAR - LH	C153	SEAL	ø28×ø42×7	No Colour	1



6	M <b>UTT</b> Motorcycles

#### 125EU5M1-F14A

ENGINE	125	APPROVAL	EU5	VERSION	M1
DIAGRAM REF.	GRO	JP REF.	GROUP		
F14A	F14		BRAKES		
		1-2	1-1		
		1-2			
		1	1-7		1-6
			1-7		HE
1—	9	1-14	4-6-6		
1-18		1-8	-15 8-∅ ) 9-©	//	
1-19 1-17	11		5 1—13		- 1-4
©≁ · · · ·				-5	1-3

							9 Motor	icycles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-1045	1141400043081	CBS BRAKE ASSEMBLY	C019	BRAKES		No Colour	1
1-1	MPT-1154	1141400038751	MASTER CYLINDER ASSEMBLY - FRONT - Ø12.7MM	C113	MASTER CYLINDER ASSEMBLY	ø12.7mm	No Colour	1
1-2	MPT-1155	1141400038752	BRAKE LEVER - FRONT BRAKE	C109	LEVER		No Colour	1
1-3	MPT-1156	1141400038731	BRAKE CALIPER - FRONT - WITH BRACKET	C030	CALIPER		No Colour	1
1-4	MPT-1157	1141400038732	BRACKET - BRAKE CALIPER - FRONT	C015	BRACKET		No Colour	1
1-5	MPT-1158	1141400038733	BRAKE PADS - FRONT - PAIR	C017	BRAKE PADS		No Colour	1
1-6	MPT-1159	1141400038753	BRAKE HOSE A - WITH SHEATH	C016	BRAKE HOSE		No Colour	1
1-7	MPT-1160	1141400038754	BRAKE HOSE B - WITH SHEATH	C016	BRAKE HOSE		No Colour	1
1-8	MPT-1161	1141400038755	BRAKE HOSE C - WITH SHEATH	C016	BRAKE HOSE		No Colour	1
1-9	MPT-1162	1141400038756	BRAKE HOSE D - WITH SHEATH	C016	BRAKE HOSE		No Colour	1
1-10	MPT-1163	1141400038757	DIVERTER VALUE	C203	VALVE		No Colour	1
1-11	MPT-0817	7012801222267	BANJO BOLT - FRONT - FINER - M10×22×1.0	C008	BANJO BOLT	M10×22×1.0	No Colour	1
1-12	MPT-1164	7012801222287	BANJO BOLT - M10×32×1.0	C008	BANJO BOLT	M10×32×1.0	No Colour	1
1-13	MPT-1165	1141400038720	MASTER CYLINDER - REAR - Ø13.5MM	C112	MASTER CYLINDER	ø13.5mm	No Colour	1
1-14	MPT-1166	1141400038830	MASTER CYLINDER CUP - WITH HOSE	C120	OIL CUP		No Colour	1
1-15	MPT-1167	1141400038850	MASTER CYLINDER CUP HOSE	C016	BRAKE HOSE		No Colour	1
1-16	MPT-1168	1610400263000	SWITCH ASSEMBLY - BRAKE - REAR	C190	SWITCH ASSEMBLY		No Colour	1
1-17	MPT-1169	1141400038760	BRAKE CALIPER - REAR - WITH BRACKET	C030	CALIPER		No Colour	1
1-18	MPT-1170	1141400038761	BRACKET - BRAKE CALIPER - REAR	C015	BRACKET		No Colour	1
1-19	MPT-1171	1141400038762	BRAKE PADS - REAR - PAIR	C017	BRAKE PADS		No Colour	1
2	MPT-0974	1041400321000	BRAKE PEDAL	C018	BRAKE PEDAL		No Colour	1
3	MPT-1147	1041400321100	BRAKE PEDAL SPRING	C176	SPRING		No Colour	1
4	MPT-0973	1290300033000	BRAKE PEDAL SPRING - ø14×ø2×45-11	C176	SPRING	ø14×ø2×45 - 11	No Colour	1
5	MPT-1148	1040700070000	BRAKE PEDAL SPACER/BUSH	C167	SPACER/BUSH	34mm	No Colour	1
6	MPT-1149	7031908000148	NUT - M8	C118	NUT	M8	No Colour	1
7	MPT-0913	7040020016008	COTTER PIN - 2×16	C051	COTTER PIN	2×16	No Colour	1
8	MPT-1150	7050008104238	ELASTIC WASHER - 8×10.1×4.2	C206	WASHER	8×10.1×4.2	No Colour	1
9	MPT-1151	7050208242038	WASHER - 8×24×2	C206	WASHER	8×24×2	No Colour	1


MUTT

M

#### 125EU5M1-F15A

ENGINE	12	25	APPROVAL	EU5	VERSION	M1		
DIAGRAM REF. GROUP REF.				GROUP				
F15A F15			CABLES, MI	RRORS, TOOL	S & MISC			


ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0318	1201000051200	MIRROR - SINGLE - WITH SWIVEL ADAPTERS - BLACK - LH	C116	MIRROR		Black	1
2	MPT-0319	1201000061200	MIRROR - SINGLE - WITH SWIVEL ADAPTERS - BLACK - RH	C116	MIRROR		Black	1
3	MPT-0404	1260300903100	CABLE TIES - 300×4.8	C029	CABLE TIES	300×4.8	No Colour	10
4	MPT-0405	1260300903200	CABLE TIES - 200×4.8	C029	CABLE TIES	200×4.8	No Colour	10
5	MPT-0434	1281400012000	THROTTLE CABLE	C026	CABLE	800mm	No Colour	1
6	MPT-1033	1281200024000	CLUTCH CABLE	C047	CLUTCH CABLE	1025mm	No Colour	1
7	MPT-1032	1281000042000	SPEEDOMETER CABLE	C026	CABLE	0	No Colour	1
8	MPT-1152	1263200121000	HOSE SLEEVE	C165	SLEEVE	0	No Colour	1
9	MPT-0375	1260100510000	WHEEL NUT RUBBER COVER - M17	C145	RUBBER COVER	M17	No Colour	1
10	MPT-0376	1260100520000	WHEEL NUT RUBBER COVER - M19	C145	RUBBER COVER	M19	No Colour	1





## 125EU5M1-E01A

ENGINE	125		APPROVAL	EU5	VERSION	M1		
DIAGRAM REF. GROUP REF.				GROUP				
E01A		E01		CYLINDER HEAD				




			-			b	Motorcy	<b>T</b> icles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0511	6260020011005	CYLINDER HEAD ASSEMBLY	C060	CYLINDER HEAD ASSEMBLY		Black	1
2	MPT-0664	6260050332000	STUD BOLT	C012	BOLT		No Colour	2
3	MPT-0940	7161098250031	RUBBER WASHER	C206	WASHER		No Colour	1
4	MPT-0790	6301063100000	PIN - 8×11	C126	PIN	8×11	No Colour	2
5	MPT-0814	7012406035166	BOLT - M6×35	C012	BOLT	M6×35	No Colour	8
6	MPT-0816	7012406060165	BOLT - M6×60	C012	BOLT	M6×60	No Colour	2
7	MPT-0760	6261020011000	CYLINDER HEAD GASKET	C088	GASKET		No Colour	1
8	MPT-0005	630106300000	PIN - 11×16	C126	PIN	11×16	No Colour	2
9	MPT-0484	6212003050002	WASHER	C206	WASHER		No Colour	2
10	MPT-0528	6260020171000	RUBBER PAD	C148	RUBBER PAD		No Colour	6
11	MPT-0951	7523708000114	NUT - M8 - CYLINDER HEAD	C118	NUT	M8	No Colour	1
12	MPT-0950	7523708000104	CAP NUT - M8	C118	NUT	M8	No Colour	3
13	MPT-0903	7032606000147	NUT - M6	C118	NUT	M6	No Colour	2
14	MPT-0482	6212003050000	GASKET	C088	GASKET		No Colour	4
15	MPT-0513	6260020032000	SPARK PLUG - NGK (CR8EA)	C168	SPARK PLUG		No Colour	1
16	MPT-0504	6260010110000	INSPECTION HOLE CAP	C104	INSPECTION HOLE CAP		No Colour	2
17	MPT-0735	6260120227000	0-RING - 3.0×29.5	C119	O-RING	3.0×29.5	No Colour	2
18	MPT-0501	6260010080000	PLUG - CYLINDER HEAD	C130	PLUG		No Colour	1
19	MPT-0706	6260090010000	TACHOMETER - DRIVEN GEAR	C192	TACHOMETER		No Colour	1
20	MPT-0759	6260500010000	CONNECTING SLEEVE	C165	SLEEVE		No Colour	1
21	MPT-0550	6260020440000	OIL SEAL	C124	OIL SEAL		No Colour	1
22	MPT-0805	7011005012157	SCREW - M5×12	C152	SCREW	M5×12	No Colour	1
23	MPT-0707	6260090030000	OIL SEAL - 5×12×18	C124	OIL SEAL	5×12×18	No Colour	1

#### 125EU5M1-E02A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM REF. GROUP REF.		GROUP				
E02A		E02		CYLINDER		

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0487	6222020004302	CYLINDER BLOCK	C059	CYLINDER BLOCK		No Colour	1
2	MPT-0637	6260050160000	STUD BOLT - L=148	C012	BOLT	148mm	No Colour	2
3	MPT-0640	6260050170000	STUD BOLT - L=153	C012	BOLT	153mm	No Colour	2
4	MPT-0667	6260050381000	STUD BOLT - L=34	C012	BOLT	34mm	No Colour	4
5	MPT-0904	7032606000245	NUT - M6	C118	NUT	M6	No Colour	4
6	MPT-0762	6261020013000	GASKET - CYLINDER	C088	GASKET		No Colour	1
7	MPT-0792	6301063300000	PIN - 11×14	C126	PIN	11×14	No Colour	2






## 125EU5M1-E03A

ENGINE	125		APPROVAL	EU5	VERSION	M1	
DIAGRAM REF. GROUP REF.		GROUP					
EO3A		E03		CRANKCASE			


ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0793	6301063400000	PIN - 13×18	C126	PIN	13×18	No Colour	2
2	MPT-0801	6401017002102	CRANKCASE	C056	CRANKCASE		No Colour	1
3	MPT-0835	7012806055103	BOLT - M6×55	C012	BOLT	M6×55	No Colour	4
4	MPT-0867	7013006060168	HEX BOLT - FLANGED - M6×60	C012	BOLT	M6×60	No Colour	4
5	MPT-0839	7012806075103	BOLT - M6×75	C012	BOLT	M6×75	No Colour	4
6	MPT-0695	6260070160000	PLATE	C129	PLATE		No Colour	1
7	MPT-0808	7012406010164	BOLT - M6×12	C012	BOLT	M6×12	No Colour	1
8	MPT-0703	6260070290000	CLIP	C043	CLIP		No Colour	1
9	MPT-0797	6301561000000	BREATHER HOSE	C020	BREATHER HOSE		No Colour	1
10	MPT-0653	6260050260000	GROUND WIRE	C208	WIRE		No Colour	1





#### 125EU5M1-E04A

ENGINE	125		APPROVAL	EU5	VERSION	M1		
DIAGRAM REF. GROUP REF.				GROUP				
E04A		E04		CRANKCASE COVER				




						G	Motorcy	<b>T</b> cles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0773	6261050190001	CLUTCH COVER	C049	CLUTCH COVER		No Colour	1
2	MPT-0654	6260050270000	LENS - OIL LEVEL	C108	LENS		No Colour	1
3	MPT-0769	6261050020000	GASKET - CLUTCH COVER	C088	GASKET		No Colour	1
4	MPT-0793	6301063400000	PIN - 13×18	C126	PIN	13×18	No Colour	2
5	MPT-0483	6212003050001	GASKET	C088	GASKET		No Colour	1
6	MPT-0830	7012806030174	BOLT - M6×30	C012	BOLT	M6×30	No Colour	9
7	MPT-0833	7012806045154	BOLT - M6×45	C012	BOLT	M6×45	No Colour	1
8	MPT-0490	6260010010000	PLUG - OIL FILLER	C130	PLUG		No Colour	1
9	MPT-0733	6260120225000	0-RING - 3.1×16.8	C119	O-RING	3.1×16.8	No Colour	1
10	MPT-0497	6260010051000	PLUG - OIL CHECK - M14×12	C130	PLUG	M14×12	No Colour	1
11	MPT-0685	6260070040000	GASKET	C088	GASKET		No Colour	1
12	MPT-0618	6260050020032	MAGNETO COVER	C054	COVER		No Colour	1
13	MPT-0679	6260070011000	MAGNETO HEAD GASKET	C088	GASKET		No Colour	1
14	MPT-0791	6301063200000	PIN - 9×12	C126	PIN	9×12	No Colour	1
15	MPT-0830	7012806030174	BOLT - M6×30	C012	BOLT	M6×30	No Colour	2
16	MPT-0831	7012806035104	BOLT - M6×35	C012	BOLT	M6×35	No Colour	2
17	MPT-0832	7012806040104	BOLT - M6×40	C012	BOLT	M6×40	No Colour	2
18	MPT-0834	7012806050104	BOLT - M6×50	C012	BOLT	M6×50	No Colour	1
19	MPT-0499	6260010060000	PLUG - TDC - M12×10	C130	PLUG	M12×10	No Colour	1
20	MPT-0691	6260070100000	GASKET	C088	GASKET		No Colour	1
21	MPT-0503	6260010090002	PLUG	C130	PLUG		No Colour	1
22	MPT-0494	6260010040000	0-RING - 3.1×22.7	C119	O-RING	3.1×22.7	No Colour	1
23	MPT-0488	6250001004002	SPROCKET COVER	C178	SPROCKET COVER		No Colour	1
24	MPT-0822	7012805025154	BOLT - M5×25	C012	BOLT	M5×25	No Colour	1
25	MPT-0826	7012805035154	BOLT - M5×35	C012	BOLT	M5×35	No Colour	2

#### 125EU5M1-E05A

ENGINE	12	25	APPROVAL	EU5	VERSION	M1
	EF.	GROL	JP REF.	GROUP		
E05A		E05		CRANKSHA	-T	


ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0567	6260030010000	CRANKSHAFT ASSEMBLY	C058	CRANKSHAFT ASSEMBLY		No Colour	1
2	MPT-0544	6260020281000	PISTON	C127	PISTON		No Colour	1
3	MPT-0547	6260020301000	PISTON RING SET	C142	RING		No Colour	1
4	MPT-0546	6260020291000	PISTON PIN	C126	PIN		No Colour	1
5	MPT-0548	6260020310000	CIRCLIP	C040	CIRCLIP		No Colour	2
6	MPT-0569	6260030020000	BEARING - RH - 28×68×17	C011	BEARING	28×68×17	No Colour	1
7	MPT-0576	6260030030000	BEARING - LH - 35×72×17	C011	BEARING	35×72×17	No Colour	1
8	MPT-0594	6260030100000	OIL SEAL - RH - 12×21×7	C124	OIL SEAL	12×21×7	No Colour	1
9	MPT-0577	6260030050000	OIL PUMP DRIVE GEAR	C065	DRIVE GEAR		No Colour	1
10	MPT-0592	6260030070000	PRIMARY DRIVE GEAR	C065	DRIVE GEAR		No Colour	1
11	MPT-0636	6260050140000	NUT - M16	C118	NUT	M16	No Colour	1
12	MPT-0596	6260030120000	LOCK WASHER	C206	WASHER		No Colour	1
13	MPT-0598	6260030131000	KEY	C105	KEY		No Colour	1
14	MPT-0603	6260030220000	ADJUSTING WASHER	C206	WASHER		No Colour	1



B	MUTT Motorcycles
	0

#### 125EU5M1-E06A


ENGINE	125	APPROVAL	EU5	VERSION	M1	ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
							MPT-0780	6261090040000	GEAR - STARTER IDLE	C089	GEAR		No Colour	1
						2	MPT-0783	6261090050000	PIN	C126	PIN		No Colour	1
DIAGRAM R	EF. GRO	UP REF.	GROUP			3	MPT-0721	6260100170000	SPACER	C166	SPACER		No Colour	1
5004					4	MPT-0642	6260050190000	CLUTCH SET STARTER	C179	STARTER		No Colour	1	
E06A	E06A E06		STARTER CL	LUICH		5	MPT-0945	7512306016164	BOLT - M6×16	C012	BOLT	M6×16	No Colour	3
L	· · ·					6	MPT-0665	6260050350000	STARTER CLUTCH GEAR ASSEMBLY	C090	GEAR ASSEMBLY		No Colour	1





## 125EU5M1-E07A

ENGINE	12	25	APPROVAL	EU5	VERSION	M1
DIAGRAM REF. GROUP REF.				GROUP		
E07A E07				CAM SHAFT	VALVE	




ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0516	6260020060000	CAMSHAFT	C032	CAMSHAFT		No Colour	1
2	MPT-0517	6260020070000	SPROCKET	C177	SPROCKET		No Colour	1
3	MPT-0535	6260020222000	PIN	C126	PIN		No Colour	1
4	MPT-0696	6260070170000	WASHER	C206	WASHER		No Colour	1
5	MPT-0605	6260030510000	BOLT - M6×10.5	C012	BOLT	M6×10.5	No Colour	2
6	MPT-0644	6260050220000	C-RING	C025	C-RING		No Colour	1
7	MPT-0518	6260020080000	ARM - VALVE ROCKER - INTAKE	C006	ARM		No Colour	2
8	MPT-0556	6260020600000	OIL SEAL - 5.5×11×8.2	C124	OIL SEAL	5.5×11×8.2	No Colour	2
9	MPT-0647	6260050241000	RETAINER SPRING	C176	SPRING		No Colour	2
10	MPT-0521	6260020090000	SHAFT - ROCKER ARM	C160	SHAFT		No Colour	2
11	MPT-0741	6260120236000	0-RING - 1.9×8.7	C119	O-RING	1.9×8.7	No Colour	2
12	MPT-0485	6212003052000	O-RING WAVE WASHER	C206	WASHER		No Colour	2
13	MPT-0484	6212003050002	WASHER	C206	WASHER		No Colour	2
14	MPT-0859	7013006025167	BOLT - M6×25	C012	BOLT	M6×25	No Colour	2
15	MPT-0522	6260020110000	VALVE - INTAKE	C203	VALVE		No Colour	1
16	MPT-0523	6260020120000	VALVE - EXHAUST	C203	VALVE		No Colour	1
17	MPT-0645	6260050230000	SPRING SET - VALVE	C176	SPRING		No Colour	2
18	MPT-0646	6260050240000	SPRING - VALVE OUTER	C176	SPRING		No Colour	2
19	MPT-0524	6260020130000	COTTER PIN - VALVE	C126	PIN		No Colour	4
20	MPT-0648	6260050242000	VALVE SPRING	C176	SPRING		No Colour	2

6 Motorcyc	<b>f</b> les
------------	-----------------

#### 125EU5M1-E09A

ENGINE	125		APPROVAL	EU5	VERSION	M1	
DIAGRAM R	EF.	GROL	JP REF.	GROUP			
E09A		E09		CAM CHAIN			


ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0525	6260020150000	CHAIN - CAM SHAFT DRIVE	C036	CHAIN		No Colour	1
2	MPT-0526	6260020160000	GUIDE - CAM CHAIN	C094	GUIDE		No Colour	1
3	MPT-0527	6260020170000	TENSIONER - CAM CHAIN	C195	TENSIONER		No Colour	1
4	MPT-0924	7060308395174	BOLT - M8×39.5	C012	BOLT	M8×39.5	No Colour	1
5	MPT-0531	6260020191000	WASHER	C206	WASHER		No Colour	1
6	MPT-0669	6260050400000	ADJUSTER - TENSIONER	C003	ADJUSTER		No Colour	1
7	MPT-0555	6260020590000	GASKET - ADJUSTER	C088	GASKET		No Colour	1
8	MPT-0857	7013006020167	BOLT - M6×20	C012	BOLT	M6×20	No Colour	2
9	MPT-0704	6260070510000	SPRING WASHER	C206	WASHER		No Colour	2





#### 125EU5M1-E10A


ENGINE	12	25	APPROVAL	EU5	VERSION	M1
DIAGRAM REF. GROUP REF				GROUP		
E10A		E10		OIL PUMP		



						G	Motorcy	<b>T</b> cles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0723	6260120030000	PUMP - ENGINE OIL	C131	PUMP		No Colour	1
2	MPT-0724	6260120040000	GEAR - OIL PUMP	C089	GEAR		No Colour	1
3	MPT-0798	6301940000000	PIN - 2.5×11.8	C126	PIN	2.5×11.8	No Colour	1
4	MPT-0728	6260120140000	CIRCLIP	C040	CIRCLIP		No Colour	1
5	MPT-0795	6301095100004	SCREW - M6×25	C152	SCREW	M6×25	No Colour	3
6	MPT-0726	6260120110003	STRAINER - ENGINE OIL	C185	STRAINER		No Colour	1
7	MPT-0927	7110605012168	SCREW - M5×12	C152	SCREW	M5×12	No Colour	2
8	MPT-0663	6260050331000	STUD BOLT - M6×85	C012	BOLT	M6×85	No Colour	1
9	MPT-0953	7523710000105	CAP NUT - M6	C118	NUT	M6	No Colour	3
10	MPT-0725	6260120050000	CAP - FILTER COVER	C033	CAP		No Colour	1
11	MPT-0736	6260120229000	0-RING - 2.4×60.5	C119	O-RING	2.4×60.5	No Colour	1
12	MPT-0829	7012806020104	BOLT - M6×20	C012	BOLT	M6×20	No Colour	3
13	MPT-0496	6260010050000	PLUG - DRAIN - M14×12	C130	PLUG	M14×12	No Colour	1
14	MPT-0685	6260070040000	GASKET	C088	GASKET		No Colour	1
15	MPT-0732	6260120200000	OIL FILTER	C122	OIL FILTER		No Colour	1
16	MPT-0734	6260120226000	0-RING - 1.9×13	C119	O-RING	1.9×13	No Colour	1
17	MPT-0729	6260120160000	SPRING	C176	SPRING		No Colour	1
18	MPT-0731	6260120170000	OIL FILTER - PAPER GASKET	C088	GASKET		No Colour	1
19	MPT-0727	6260120120000	0-RING - 2.4×52.6	C119	O-RING	2.4×52.6	No Colour	1
20	MPT-0003	626012028000	OIL FILTER CAP	C123	OIL FILTER CAP		No Colour	1
21	MPT-0662	6260050330000	STUD BOLT - M6×12	C012	BOLT	M6×12	No Colour	2

## 125EU5M1-E11A


ENGINE	12	25	APPROVAL	EU5	VERSION	M1
	EF.	GROL	JP REF.	GROUP		
E11A		E11		CLUTCH		



							B Mator	<b>ITT</b> vcycles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0620	6260050060000	PRIMARY DRIVE GEAR ASSEMBLY	C066	DRIVE GEAR ASSEMBLY		No Colour	1
2	MPT-0693	6260070140000	WASHER	C206	WASHER		No Colour	2
3	MPT-0631	6260050091000	CLUTCH SLEEVE - SPLINED	C165	SLEEVE		No Colour	1
4	MPT-0595	6260030110000	NUT - M16	JT - M16 C118 NU		M16	No Colour	1
5	MPT-0688	6260070090000	LOCK WASHER	C206	WASHER		No Colour	1
6	MPT-0621	6260050061000	PUSH ROD		No Colour	1		
7	MPT-0627	6260050070000	ACTIVE FRICTION PLATE	C067	DRIVEN PLATE		No Colour	5
8	MPT-0625	6260050066000	DRIVEN PLATE	C067	DRIVEN PLATE		No Colour	4
9	MPT-0632	6260050092000	CLUTCH SPRING PRESSURE PLATE	C129	PLATE		No Colour	1
10	MPT-0635	6260050130000	CLUTCH SPRING	C176	SPRING		No Colour	5
11	MPT-0807	7012405016172	BOLT - M5×16	C012	BOLT	M5×16	No Colour	5
12	MPT-0948	7512506010168	CLUTCH ROCKER HEX SCREW - M6×10	C152	SCREW	M6×10	No Colour	1
13	MPT-0622	6260050062000	CLUTCH COLUMN TOP	C045	CLUTCH		No Colour	1
14	MPT-0623	6260050063000	CAMSHAFT - CLUTCH RELEASE	C032	CAMSHAFT		No Colour	1
15	MPT-0694	6260070150000	WASHER	C206	WASHER		No Colour	1
16	MPT-0699	6260070200000	WASHER	C206	WASHER		No Colour	1
17	MPT-0574	6260030026000	THRUST BEARING	C011	BEARING		No Colour	1
18	MPT-0549	6260020400000	OIL SEAL	C124	OIL SEAL		No Colour	1
19	MPT-0563	6260025064000	SCREW - M6×25	C152	SCREW	M6×25	No Colour	1
20	MPT-0895	7031906000153	NUT - M6	C118	NUT	M6	No Colour	1
21	MPT-0630	6260050090000	CLUTCH ARM	C046	CLUTCH ARM		No Colour	1
22	MPT-0946	7512406010164	SCREW - M6×16	C152	SCREW	M6×16	Chrome	1
23	MPT-0701	6260070262000	WASHER	C206	WASHER		No Colour	1
24	MPT-0785	6261090070000	LARGE INNER CLUTCH HUB SLEEVE/SPACER	C166	SPACER		No Colour	1

#### 125EU5M1-E12A


ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM R	EF.	GROL	JP REF.	GROUP		
E12A E12				TRANSMISS	ION	



						G	Motorcy	<b>T</b> cles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0615	6260040040001	COUNTERSHAFT ASSEMBLY - WITHOUT GEAR	C053	COUNTERSHAFT ASSEMBLY		No Colour	1
2	MPT-0681	6260070014000	BEARING RING	C206	WASHER		No Colour	1
3	MPT-0570	6260030021000	BEARING - RH	C011	BEARING		No Colour	1
4	MPT-0571	6260030022000	BEARING - LH	C011	BEARING		No Colour	1
5	MPT-0682	6260070015000	BEARING BRACKET	C015	BRACKET		No Colour	1
6	MPT-0884	7022006012165	SCREW - M6×12	C152	SCREW	M6×12	No Colour	2
7	MPT-0573	6260030024000	BEARING - RH	C011	BEARING		No Colour	1
8	MPT-0572	6260030023000	BEARING - LH	C011	BEARING		No Colour	1
9	MPT-0682	6260070015000	BEARING BRACKET	C015	BRACKET		No Colour	1
10	MPT-0884	7022006012165	SCREW - M6×12	C152	SCREW	M6×12	No Colour	2
11	MPT-0608	6260040020000	OIL SEAL - LH	C124	OIL SEAL		No Colour	1
12	MPT-0672	6260060040000	DRIVESHAFT BAFFLE SEAL	C153	SEAL		No Colour	1
13	MPT-0808	7012406010164	BOLT - M6×12	C012	BOLT	M6×12	No Colour	2
16	MPT-0670	6260060010000	CHAIN WHEEL	C177	SPROCKET	13T	No Colour	1
17	MPT-0787	6261090071000	SPACER	C166	SPACER		No Colour	1
18	MPT-0505	6260010230000	0-RING - 19×2.4	C119	O-RING	19×2.4	No Colour	1
19	MPT-0910	7034216000146	NUT - M16×1.5	C118	NUT	M16×1.5	No Colour	1
20	MPT-0671	6260060020000	WASHER	C206	WASHER		No Colour	1
23	MPT-0673	6260060050000	DRIVESHAFT	C068	DRIVESHAFT		No Colour	1
24	MPT-0614	6260040040000	COUNTERSHAFT ASSEMBLY - WITH GEAR	C053	COUNTERSHAFT ASSEMBLY		No Colour	1
25	MPT-0607	6260040010000	DRIVESHAFT	C068	DRIVESHAFT		No Colour	1

#### 125EU5M1-E13A

ENGINE	12	125 APPROVAL EU5		VERSION	M1	
DIAGRAM REF.		GROL	JP REF.	GROUP		
E13A		E13		GEAR SHIFT		




_						G	) Motorcy	<b>T</b> cles
ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0655	6260050290000	GEAR SHIFT FORK (1)	C077	FORK		No Colour	2
2	MPT-0668	6260050390000	GEAR SHIFT FORK (3)	C077	FORK		No Colour	1
3	MPT-0656	6260050300000	SHAFT - FORK (1)	C160	SHAFT		No Colour	1
4	MPT-0661	6260050310000	SHAFT - FORK (2)	C160	SHAFT		No Colour	1
5	MPT-0715	6260100090000	CAM - GEAR SHIFTING	C031	CAM		No Colour	1
6	MPT-0709	6260100011000	STOPPER PLATE	C184	STOPPER		No Colour	1
7	MPT-0710	6260100012000	CAM - DRIVEN GEAR	C031	CAM		No Colour	1
8	MPT-0537	6260020223000	PAWL (1)	C125	PAWL		No Colour	1
9	MPT-0538	6260020224000	PAWL (2)	C125	PAWL		No Colour	1
10	MPT-0534	6260020220000	SHAFT PIN	C126	PIN		No Colour	2
11	MPT-0748	6260120360000	SPRING	C176	SPRING		No Colour	2
12	MPT-0674	6260060060000	LIFTER - PAWL	C125	PAWL		No Colour	1
13	MPT-0884	7022006012165	SCREW - M6×12	C152	SCREW	M6×12	No Colour	2
14	MPT-0675	6260060061000	CAM GUIDE	C094	GUIDE		No Colour	1
15	MPT-0884	7022006012165	SCREW - M6×12	C152	SCREW	M6×12	No Colour	2
16	MPT-0677	6260060070000	CAM STOPPER	C184	STOPPER		No Colour	1
17	MPT-0809	7012406016267	BOLT - M6×16	C012	BOLT	M6×16	No Colour	1
18	MPT-0680	6260070013000	WASHER	C206	WASHER		No Colour	1
19	MPT-0541	6260020240000	CAM PIN SPRING - TOP	C176	SPRING		No Colour	1
20	MPT-0713	6260100070000	SPRING	C176	SPRING		No Colour	1
21	MPT-0542	6260020250000	ноок	C126	PIN		No Colour	1
22	MPT-0539	6260020225000	NEUTRAL STOPPER	C126	PIN		No Colour	1
23	MPT-0883	7022005020165	PHILLIPS HEAD SCREW - M5×20	C152	SCREW	M5×20	No Colour	2
24	MPT-0536	6260020222200	PIN - 4×6	C126	PIN	4×6	No Colour	1
25	MPT-0498	6260010052000	PLUG - CAM STOPPER	C130	PLUG	M14×12	No Colour	1
26	MPT-0685	6260070040000	GASKET	C088	GASKET		No Colour	1
27	MPT-0718	6260100120000	SHAFT - GEAR SHIFTING	C160	SHAFT		No Colour	1
28	MPT-0717	6260100100000	SPACER	C166	SPACER		No Colour	1
29	MPT-0540	6260020230000	SHIFTING SHAFT TORSION SPRING	C176	SPRING		No Colour	1
30	MPT-0719	6260100140000	STOPPER - GEAR SHIFT ARM	C184	STOPPER		No Colour	1
31	MPT-0711	6260100030000	OIL SEAL	C124	OIL SEAL		No Colour	1
32	MPT-0712	6260100040000	TERMINAL BASE ASSEMBLY	C196	TERMINAL BASE ASSEMBLY		No Colour	1
33	MPT-0738	6260120230000	0-RING - 24×26.2	C119	O-RING	24×26.2	No Colour	1
34	MPT-0750	6260120460000	SPRING	C176	SPRING		No Colour	1
35	MPT-0751	6260120461000	CONTACT PIN	C126	PIN		No Colour	1
36	MPT-0043	1040400122000	GEAR LEVER - BLACK	C109	LEVER		Black	1
37	MPT-0698	6260070190000	WASHER	C206	WASHER		No Colour	1

#### 125EU5M1-E14A

ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM R	EF.	GROU	JP REF.	GROUP		
E14A		E14		STARTING M	IOTOR	

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0708	6260090070000	STARTER MOTOR ASSEMBLY	C180	STARTER MOTOR ASSEMBLY		No Colour	1
2	MPT-0742	6260120238000	0-RING - 3×24.5	C119	O-RING	3×24.5	No Colour	1
3	MPT-0830	7012806030174	BOLT - M6×30	C012	BOLT	M6×30	No Colour	2








#### 125EU5M1-E15A


ENGINE	125		APPROVAL	EU5	VERSION	M1
DIAGRAM REF.		GROUP REF.		GROUP		
E15A		E15		MAGNETO		

ITEM NO.	MUTT PART NO.	BARCODE REF.	PART DESCRIPTION	CAT CODE	CATEGORY	SIZE	COLOUR	QTY.
1	MPT-0777	6261070034000	STATOR ASSEMBLY (ALTERNATOR)	C182	STATOR		No Colour	1
2	MPT-0779	6261070045000	FLYWHEEL	C075	FLYWHEEL		No Colour	1
3	MPT-0928	7110605025153	SCREW - M5×25	C152	SCREW	M5×12	No Colour	3
4	MPT-0878	7021804012263	SCREW - M4×12	C152	SCREW	M4×12	No Colour	2
5	MPT-0500	6260010062000	NUT - M10	C118	NUT	M10	No Colour	1
6	MPT-0597	6260030130000	KEY - 3×13	C105	KEY		No Colour	1
7	MPT-0775	6261070030000	MAGNETO	C111	MAGNETO		No Colour	1





## WIRING DIAGRAM





37

## TORQUE SETTINGS

MAIN CHASSIS AND WHEEL COMPONENTS	5-10 NM	15-20 NM	25-30 NM	35-40 NM	45-50 NM	55-60 NM	65-70 NM	75-80NM	MAIN ENGINE COMPONENTS	5-10 NM	15-20 NM	25-30 NM	35-40 NM	45-50 NM	55-60 NM	65-70 NM	75-80NM
Front and Rear Axle						<b>Ø</b>			Front Engine Cradle Bolts					<b>Ø</b>			
Rear Sprocket				<b>Ø</b>					Top Engine Mount Bolts					<b>Ø</b>			
Brake Disc Bolts Front/Rear			<b>I</b>						Rear Engine Mount Bolt					<b>Ø</b>			
Shock Nuts			0						Exhaust Header Bolts			<b>Ø</b>					
Fork Top Hat					0				Exhaust Coupler		<b>Ø</b>						
Fork Damper Rod Retaining Bolt			<b>I</b>						Exhaust Silencer Mount			<b>I</b>					
Front/Rear Fender Bracket Mounting Bolts			0						Exhaust Lambda Sensor		<b>Ø</b>						
Fender Bolts		<b>Ø</b>							Cylinder Head Studs			<b>Ø</b>					
Bar Clamps			0						Barrel Retainers		<b>Ø</b>						
Steering Stem Top Nut						0			Cam Cover Bolts		0						
Bottom Yoke Pinch Bolts				<b>Ø</b>					Cam Gear Bolt		<b>Ø</b>						
Top Yoke Pinch Bolts				0					Cam Tensioner Bolts		0						
Clutch Perch									Oil Drain Plug			<b>I</b>					
Front Brake Perch		<b>I</b>							Oil Filter Housing		0						
Swing Arm Axle						<b>Ø</b>			Oil Sump Gauze Cover Bolts		Ø						
Foot Pegs					<b>Ø</b>				Clutch Basket Main Nut					<b>Ø</b>			
Rear Frame Loop			0						Flywheel Main Nut						<b>Ø</b>		
									Front Sprocket						<b>I</b>		



## HANDOVER - PRE-DELIVERY INSPECTION CHECKLIST

	ІТЕМ	
PRE-BU	ILD QUALITY CHECKS	
	Check for any significant paintwork issues or physical damage	
RAMP D	OWN	
1	Check battery and charge if necessary.	
2	Fit battery terminals, ensuring terminals are tight and terminal protection spray is used.	
3	Fit adjust and tighten mirrors.	
4	Check throttle and clutch cable for free play and correct operation.	
5	Check routing of cables and wiring, handlebars move freely from lock to lock.	
6	Check brake fluid levels, top up if necessary.	
RAMP L	IP	
7	Check and clean front and rear brake discs.	
8	Check fitment of all brake pads.	
9	Visual check of tyre and wheel, check for tyre fitment and rim run out.	
10	Check wheel spokes are tensioned.	
11	Check tyre pressures.	
12	Check front wheel bearings.	
13	Check rear wheel bearings.	
14	Check steering head bearings, smooth from lock to lock.	
15	Check front axle is tight.	
16	Check chain drive tension and alignment.	
17	Check swing arm bearings.	

	ITEM
18	Check shock bolts are tight.
19	Check rear axle is tight.
20	Check oil level.
21	Fit registration plate.
22	Check all low level fastenings are tight - ALL IN VIEW
23	Tail Light
RAMP D	OWN
24	Add fuel (5 Litres unless otherwise requested).
25	Turn on ignition - check for fuel pump priming/fuel l
26	Start bike and run up to temperature.
27	Check all lights and switches - High & Low Beam/In
28	Check kill switch.
29	Move steering from lock to lock, check for idle chang
30	Check battery and charging system.
31	Check side stand cut out switch is operational.
32	Check / fit tool kit.
33	Check headlamp aim/height - adjust if necessary.
34	Check steering lock and ignition switch.
35	Check smooth operation of front and rear suspensio
36	Switch off bike - recheck oil level.
	Continues on next page



V	
leaks.	
Indicators/Horn.	
iges.	
on.	

## HANDOVER - PRE-DELIVERY INSPECTION CHECKLIST

	ІТЕМ	
ROAD TE	EST (3 MILE MINIMUM)	
37	IMPORTANT! PERFORM ROAD TEST (3 mile minimum)	
38	No unusual engine noises or rattles.	
39	Easy hot restart and smooth idling.	
FINAL C	HECKS	
40	Re-check oil level.	
41	Re-check final drive for tension and alignment.	
42	Clean/polish bike ready for handover.	
43	Final visual check for any oil leaks.	
HANDO\	/ER	
44	Technician - Sign PDI	
45	Owners hand book/warranty book.	
46	Owners tool kit.	
47	MUTT warranty registration form/certificate.	
48	Spare keys	
49	Customer - Sign PDI	
54	MUTT warranty registration form/certificate.	
55	Spare keys	
56	Customer - Sign PDI	



## SERVICE INFORMATION - SERVICE SCHEDULE & GENERAL GUIDANCE

It is important that regular servicing is carried out on our motorcycles. The service schedule is outlined below. Please follow the detailed service procedures outlined for each service.

Service schedule and procedures apply to **all 125cc and 250cc bike models**.

SERVICE	INTERVAL
FIRST SERVICE	800KM
SECOND SERVICE	4,000KM
THIRD SERVICE	8,000KM
FOURTH SERVICE	12,000KM
FIFTH SERVICE	16,000KM
SIXTH SERVICE ONWARDS	Every +4,000KM from 20,000KM on

### CAUTION

Proper service and repair procedures are essential for the service technician's safety and the motorcycle's safety and reliability. When two or more people work together, pay attention to each other's safety. When it is necessary to run the engine indoors, ensure removal of any exhaust gas using extraction. When working with any toxic or flammable materials, make sure that the area you work in is well ventilated and that you follow all of the material manufacturer's instructions. Never use petrol as a cleaning solvent. To avoid getting burned, do not touch the engine, engine oil or exhaust system during or shortly after engine operation. After servicing the fuel, oil, exhaust or brake system, check all lines and fittings related to these systems for leakage. When working on the brake system, when completed, ALWAYS ensure proper brake system operation.

If parts replacement is necessary, replace the parts with MUTT genuine or approved parts. When removing parts that will be re-used, keep them arranged in an orderly manner for re-installation in the proper order and orientation. Make sure that all components used in reassembly are clean and lubricated where specified. When performing service to electrical parts, if the service procedures do not require battery power, disconnect the positive terminal. When removing the battery, disconnect the negative cable first and then the positive cable. When reconnecting the battery, connect the positive cable first and then the negative cable, and replace the terminal cover on the positive terminal. Whenever you remove oil seals, gaskets, packing, O-rings, locking washers, cotter pins, circlips, and certain other parts as specified, be sure to replace them with new ones. Before installing new parts, remove any unwanted material from the mating surfaces. After installing a circlip, always ensure that it is completely seated in its groove and securely fitted. Do not re-use locking nuts. Use a torque wrench to tighten fasteners to the torque values specified. After reassembly, check parts for tightness and correct operation.

### SUSTAINABILITY

To protect the environment, do not unlawfully dispose of used motor oil and other fluids, batteries and tyres. To ensure that we operate as sustainably as possible, always ensure proper disposal of used motorcycle parts. Whenever possible, we should find ways to recycle and re-use parts and components.

#### IMPORTANT

Please note that the warnings and the cautions contained in this manual cannot cover all potential hazards relating to the servicing, or lack of servicing, of the motorcycle. In addition to the WARNING and CAUTION stated, you must use good judgment and basic mechanical safety principles. If you are unsure how to perform a particular service operation, ask a more experienced technician for advice.



## SERVICE INFORMATION - FIRST SERVICE

### SUMMARY

- PREPARE THE MOTORCYCLE
- 2. CHECK LIGHTING SYSTEMS
- 3. CHECK ELECTRONIC HAND CONTROLS
- TURN OFF THE MOTORCYCLE 4.
- DRAIN OIL 5.
- REMOVE AND REPLACE OIL FILTER 6.
- REPLACE OIL 7.
- 8. CLEAN AIR FILTER
- 9. CHECK SPARK PLUG
- CHECK REAR WHEEL AND TYRE 10.
- CHECK AND LUBRICATE CHAIN 11.
- 12. CHECK FRONT WHEEL AND TYRE
- DIAGNOSTIC CHECK 13.
- FINAL CHECK & CLEAN 14.

#### PREPARE THE MOTORCYCLE 1.

1.1.

- Place the motorcycle on the ramp and secure safely.
- Starting and warming the motorcycle is required to thin the 1.2. engine oil to make it easier to drain. Start the bike in the usual manner; make sure the bike is in neutral, pull in the clutch and make sure the side stand is up.

#### CHECK LIGHTING SYSTEMS 2.

- With the bike running check the lighting systems: 2.1.
- Headlight: Check that the headlight and sidelight bulbs are 2.2. running to their full capacity.
- 2.3. Main beam: Check that the main beam bulb is running at full capacity when switched on. Make sure that this doesn't affect any other headlight bulbs when switched on.
- 2.4. Front and rear indicators: Check that all four indicators are flashing at the correct speed (60-120 FPM) and that none of the bulbs is dim or defective.
- **2.5. Rear running light:** Check that the rear day running light is continuously running without any intermittent flashes or flickers.
- **2.6.** Brake light and front and rear actuators: Check the rear brake light operation by placing one hand over the rear light cluster and pulling the front brake lever. Do the same again for the rear using your foot to press down the brake pedal.
- 2.7. Number plate light: Place your fingers underneath the light cluster checking for the bright white light.
- 2.8. If any of the above are not working of defective, consult the troubleshooting advice.

#### 3. CHECK ELECTRONIC HAND CONTROLS

- 3.1. With the bike still running, check the electronic hand controls:
- Main beam flash switch: Check if the main beam switches on/ 3.2. off using the yellow button on the LHS switchgear. Do this a few times, releasing the switch to check that the main beam goes off correctly.
- Main beam switch: Switch the main beam switch to the on 3.3. position and check if the main beam is on. Check the main beam indicator light is on.

- 3.4. Horn button: Press the horn button on the LHS switchgear an ensure the horn is triggered and audible.
- Indicator switch and cancelling operation: Confirm the 3.5. indicators operate correctly by sliding the indicator switch from right to left. Click the indicator switch entirely in to check the cancelling operation.
- Kill switch operation: Move the red kill switch to the 'off' position. 3.6. Restart the bike to continue warming the oil.
- TURN OFF THE MOTORCYCLE 4.
- 4.1.

## DRAIN OIL

5.

5.1.

5.2.

- has no sump guard, move to step 5.3 Remove the sump guard using a 10mm socket or spanner. Undo the three 10mm bolts securing the sump guard plate in place. Keep these bolts safe. Check the anti-vibration rubber grommets fitted to the sump guard plate. Replace if torn or perished or showing other signs of wear. Worn grommets can cause severe vibration and excessive wear on the sump guard mounting points if they are not replaced. Remove the oil filler cap for better oil flow whilst draining. Ensure that your oil drain tub is directly under the engine. Using a 5.3. 17mm socket with an extension secured on the head of the sump plug, remove the plug by turning counter-clockwise. The sump plug is located on the triangular plate underneath the engine, directly in the middle. CAUTION - The oil will be extremely hot - remove with care. We recommend that you wear heat-resistant rubber gloves during the draining process.
- Clean and check the threads and washer on the sump plug. If there 5.4. is any damage to either the threads or the washer, replace the sump plug. Replace the sump plug washer after a maximum of two oil changes.



After three minutes of run time, turn the motorcycle off. Be careful around the bike once it is warmed up, particularly around the engine and exhaust, as it will now be hot.

Use a suitable drain tub with a capacity of 1L or above. If the bike

## SERVICE INFORMATION - FIRST SERVICE (Cont.)

- Visually check the oil that is draining, looking for any obvious 5.5. metal particulates. If metal particulates are present, then consult the troubleshooting advice.
- Leave the oil to drain for approximately three minutes. Make sure 7.3. 5.6. the bike stays in the upright position throughout.
- 5.7. Once the oil has drained completely, refit the sump plug, ensuring that the washer is still fitted correctly. Tighten the sump plug clockwise to 25nm f. DO NOT overtighten the sump plug as there is a risk of stripping internal threads. Always make sure you pay attention to our torque specifications and observe the correct settings.
- 5.8. Clean any oil residue off of the engine using brake cleaner.

#### 6. REMOVE AND REPLACE OIL FILTER

- It is essential to change the oil filter during the first service. After 6.1. the break-in process, metal particulates can gather in the oil filter. This is entirely normal and indicates that the engine has bedded in correctly.
- Ensure that your drain tub is still underneath the motorcycle, then 6.2. remove the three oil filter house nuts using a 10mm socket. Once removed, ease the oil filter housing cap away from the crankcase. Ensure you remove the cap carefully and try not to tear or damage 8. the paper gasket or rubber O-ring. If you damage these items during this process, they will need replacement.
- Remove the oil filter by extracting the filter out of the filter 6.3. housing. Inspect the oil filter, looking for any obvious signs of damage. Remember that it is normal to find metal particles, especially during the first service.
- Fit a new oil filter into the housing, ensuring that the oil filter is in 8.2. 6.4. the correct orientation.
- Refit the oil filter housing, ensuring the correct fitting of the o-ring 6.5. and paper gasket. Tighten the three 10mm nuts to 15nm.

#### REPLACE OIL 7.

Remove the oil filler cap. Place a funnel in the oil fill port. Measure 7.1. out 900MLs of 10w40 semi-synthetic motorcycle oil. Place the oil 9. into the engine slowly, being careful not to spill any oil.

- 7.2. After adding the required amount of oil, replace the oil filler cap and check for any leaks on the sump plug. Remove the drain tub and dispose of the oil accordingly.
  - When you are confident the oil level is correct and that there are no apparent leaks, run the engine for approximately one minute to circulate the oil and refill the oil filter with clean oil. Start the motorcycle in the usual manner. Remember to run the motorcycle outside or with a ventilation system in place. Be careful of the hot engine and exhaust whilst running. If you find any leaks during the running process, turn the motorcycle off immediately. Trace the source and consult troubleshooting advice.
- After running for one minute, turn the motorcycle off and leave 7.4. for three minutes to cool. Check the oil by looking at the oil level window making sure the bike is entirely upright. If the oil level is below the centre of the window, remove the oil filler cap and add more oil until the window is 3/4 filled. Refit the oil filler cap and clean off any residue.
- Refit the sump guard by bolting the sump guard plate back on to 7.5. the sump guard mount. Fit the rubber grommets. Tighten the three 10mm sump guard plate bolts up to 40nm.

## **CLEAN AIR FILTER**

8.1. Gain access to the airbox by removing the airbox side cover. Remove the three screws that hold the air filter tube in place. Slide the air filter tube out of the airbox. Remove the air filter from the tube. If you have access to an air compressor with an airline nozzle, use it to blow the air filter clean. If you do not have a compressor, clean thoroughly in warm water, then leave to dry. Spray the air filter with air filter oil to the directions supplied by the manufacture of the product you are using. Refit the air filter by placing it back over the tube and slide it back into the airbox. Tighten the three screws to secure the air filter tube back into the airbox. Put the airbox cover back on, making sure that the rubber grommets are secured correctly.

## CHECK SPARK PLUG

9.1. Remove the spark plug cap. Use a 10mm spark plug socket to remove the spark plug, screwing counter-clockwise. Check the plug tip and side electrode. If they have turned entirely black, it can indicate a problem linked to the spark plug operation. If this is the case, see our troubleshooting advice for guidance.

- then replace with a new one.
- 9.4. makes a click.

9.2.

9.3.

10.1.

#### 10. CHECK REAR WHEEL AND TYRE

10.2.

#### 11. CHECK AND LUBRICATE CHAIN

- 11.1. of the chain.
- 11.2. tensioner block.
- 11.3.



Using a feeler gauge, check the spark plug gap, which should be 0.7-0.8mm. If you are not happy with the spark plug's condition,

Once you are happy with the spark plug's condition (or have replaced for new), you can refit. Using a 10mm spark plug socket tighten to 25nm. Once torqued to spec, give it a small nip with a ratchet to check that the crush washer is fully seated.

Push the spark plug cap onto the spark plug, making sure it

Jack the rear of the motorcycle up on the ramp using the jack point. Spin the wheel looking for any nails or objects that have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.

Check the rear tire pressure is at the required 2.2 bar/32 psi. If the pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.

With the wheel jacked in the air, check the tension and lubrication

Slack off the rear wheel axle to release tension from the chain

Loosen the lock nut off the adjuster by a few centimetres. Rotate the adjusting bolt using the increment marks on the swingarm as a guide. Ensuring the symmetrical movement of both left and right tensioners, check the chain tension. We recommend moving between 4-5mm. Take this measurement from the swingarm to the bottom of the chain. Tighten the adjuster lock nuts and rear axle nut. Fit the rubber axle nut cap securely.

## SERVICE INFORMATION - FIRST SERVICE (Cont.)

- 11.4. To lubricate the chain, spin the wheel and spray the chain lube directly onto the chain. Remember to pay attention to the instructions of the product. Make a few passes then wipe the brake disc and tire clean.
- 11.5. Lower the jack and turn the bike around. Always make sure the bike is secured on the ramp when doing this. With the bike in the reverse position on the ramp, jack the front wheel into the air using the jacking point.

## 12. CHECK FRONT WHEEL AND TYRE

- 12.1. With the front wheel jacked up into the air, spin the wheel looking for any nails or objects that may have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- 12.2. Check the rear tire pressure is at the required 2.2 bar/32 psi. If the pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.
- 12.3. Lower and remove the jack from underneath the motorcycle.

## 13. DIAGNOSTIC CHECK

13.1. Remove the seat and find the diagnostics port. Remove the waterproof cover and plug in the MUTT diagnostic scanner. Follow the on-screen instructions and run an error code test. Consult our P codes troubleshooting booklet for guidance for any error codes shown. Refit the waterproof diagnostics port cover and refit the side panel if the test is clear.

## 14. FINAL CHECK & CLEAN

- 14.1. To complete the service, final lubrication and cleaning are required. Lubricate the following parts:
- 14.2. **Rider footpegs:** lubricate with white grease or penetrating oil. Wipe off ALL overspray from the exhaust and brake pedal.
- 14.3. **Passenger footpegs:** lubricate with white grease or penetrating oil as with the rider footpegs. Wipe ALL overspray from the exhaust and brake pedal.

- 14.4. Brake pedal pivot bush: lubricate with white grease or penetrating oil.
- 14.5. Clean and polish the motorcycle thoroughly before returning it to the customer. We recommended using our MUTT cleaning product range for the best finish possible. Cleaning the bike is also an opportunity to check for any other issues that may need attention. Remember always to use brake cleaner to clean brake discs after using any cleaning products.
- 14.6. Stamp and sign the service booklet once the service is complete. And you're done - great work!



## SERVICE INFORMATION - SECOND & THIRD SERVICE

## SUMMARY

- PREPARE THE MOTORCYCLE
- 2. CHECK LIGHTING SYSTEMS
- 3. CHECK ELECTRONIC HAND CONTROLS
- TURN OFF THE MOTORCYCLE 4.
- 5. DRAIN OIL
- INSPECT AND CLEAN OIL STRAINER 6.
- REMOVE AND REPLACE OIL FILTER 7.
- 8. REPLACE OIL
- 9. CLEAN AIR FILTER
- CHECK SPARK PLUG 10.
- CHECK BRAKE SYSTEM 11.
- 12. CHECK AND ADJUST CLUTCH LEVER
- CHECK REAR WHEEL AND TYRE 13.
- 14. CHECK AND LUBRICATE CHAIN
- CHECK FRONT WHEEL AND TYRE 15.
- CHECK HEADRACE BEARING 16.
- 17. DIAGNOSTIC CHECK
- 18. **FINAL CHECK & CLEAN**

#### PREPARE THE MOTORCYCLE 1.

- Place the motorcycle on the ramp and secure safely. 1.1.
- Starting and warming the motorcycle is required to thin the 1.2. engine oil to make it easier to drain. Start the bike in the usual manner; make sure the bike is in neutral, pull in the clutch and make sure the side stand is up.

#### CHECK LIGHTING SYSTEMS 2.

- With the bike running check the lighting systems: 2.1.
- Headlight: Check that the headlight and sidelight bulbs are 2.2. running to their full capacity.
- 2.3. Main beam: Check that the main beam bulb is running at full capacity when switched on. Make sure that this doesn't affect any other headlight bulbs when switched on.
- 2.4. Front and rear indicators: Check that all four indicators are flashing at the correct speed (60-120 FPM) and that none of the bulbs is dim or defective.
- **Rear running light:** Check that the rear day running light is 2.5. continuously running without any intermittent flashes or flickers.
- **2.6.** Brake light and front and rear actuators: Check the rear brake light operation by placing one hand over the rear light cluster and pulling the front brake lever. Do the same again for the rear using your foot to press down the brake pedal.
- 2.7. Number plate light: Place your fingers underneath the light cluster checking for the bright white light.
- 2.8. If any of the above are not working of defective, consult the troubleshooting advice.

#### 3. CHECK ELECTRONIC HAND CONTROLS

- 3.1. With the bike still running, check the electronic hand controls:
- Main beam flash switch: Check if the main beam switches on/ 3.2. off using the yellow button on the LHS switchgear. Do this a few times, releasing the switch to check that the main beam goes off correctly.
- Main beam switch: Switch the main beam switch to the on 3.3. position and check if the main beam is on. Check the main beam indicator light is on.

- 3.4. Horn button: Press the horn button on the LHS switchgear an ensure the horn is triggered and audible.
- Indicator switch and cancelling operation: Confirm the 3.5. indicators operate correctly by sliding the indicator switch from right to left. Click the indicator switch entirely in to check the cancelling operation.
- Kill switch operation: Move the red kill switch to the 'off' position. 3.6. Restart the bike to continue warming the oil.
- TURN OFF THE MOTORCYCLE 4.
- 4.1.

## DRAIN OIL

5.

5.1.

5.2.

- Use a suitable drain tub with a capacity of 1L or above. If the bike has no sump guard, move to step 5.3 Remove the sump guard using a 10mm socket or spanner. Undo the three 10mm bolts securing the sump guard plate in place. Keep these bolts safe. Check the anti-vibration rubber grommets fitted to the sump guard plate. Replace if torn or perished or showing other signs of wear. Worn grommets can cause severe vibration and excessive wear on the sump guard mounting points if they are not replaced. Remove the oil filler cap for better oil flow whilst draining. Ensure that your oil drain tub is directly under the engine. Using a 5.3. 17mm socket with an extension secured on the head of the sump plug, remove the plug by turning counter-clockwise. The sump plug is located on the triangular plate underneath the engine, directly in the middle. CAUTION - The oil will be extremely hot - remove with care. We recommend that you wear heat-resistant rubber gloves during the draining process.
- Clean and check the threads and washer on the sump plug. If there 5.4. is any damage to either the threads or the washer, replace the sump plug. Replace the sump plug washer after a maximum of two oil changes.



After three minutes of run time, turn the motorcycle off. Be careful around the bike once it is warmed up, particularly around the engine and exhaust, as it will now be hot.

## SERVICE INFORMATION - SECOND & THIRD SERVICE (Cont.)

- 5.5. Visually check the oil that is draining, looking for any obvious metal particulates. If metal particulates are present, then consult the troubleshooting advice.
- Leave the oil to drain for approximately three minutes. Make sure 5.6. the bike stays in the upright position throughout.
- 5.7. Once the oil has drained completely, refit the sump plug, ensuring that the washer is still fitted correctly. Tighten the sump plug clockwise to 25nm f. DO NOT overtighten the sump plug as there is a risk of stripping internal threads. Always make sure you pay attention to our torque specifications and observe the correct settings.
- 5.8. Clean any oil residue off of the engine using brake cleaner.

#### 6. INSPECT AND CLEAN OIL STRAINER

- Unbolt the strainer cover this is the metal triangle that the oil 6.1. sump plug threads onto. Loosen the bolts and remove being careful not to damage the O-ring.
- Remove the oil strainer and clean off any metal particulates by 6.2. washing thoroughly with brake cleaner. If there are any unusual sized parts of metal, consult the troubleshooting advice.
- Once clean, reinstall the strainer and bolt the cover back on, 6.3. ensuring the O-ring is still in place. Torque the bolts to 25nm in a diagonal pattern.

#### REMOVE AND REPLACE OIL FILTER 7.

- 7.1. It is essential to change the oil filter during the first service. After the break-in process, metal particulates can gather in the oil filter. This is entirely normal and indicates that the engine has bedded in correctly.
- Ensure that your drain tub is still underneath the motorcycle, then 7.2. remove the three oil filter house nuts using a 10mm socket. Once removed, ease the oil filter housing cap away from the crankcase. Ensure you remove the cap carefully and try not to tear or damage the paper gasket or rubber O-ring. If you damage these items during this process, they will need replacement.
- Remove the oil filter by extracting the filter out of the filter 7.3. housing. Inspect the oil filter, looking for any obvious signs of

damage. Remember that it is normal to find metal particles, especially during the first service.

- Fit a new oil filter into the housing, ensuring that the oil filter is in 9.2. 7.4. the correct orientation.
- Refit the oil filter housing, ensuring the correct fitting of the o-ring 7.5. and paper gasket. Tighten the three 10mm nuts to 15nm.

## REPLACE OIL

8.

- Remove the oil filler cap. Place a funnel in the oil fill port. Measure 8.1. out 900MLs of 10w40 semi-synthetic motorcycle oil. Place the oil into the engine slowly, being careful not to spill any oil.
- 8.2. After adding the required amount of oil, replace the oil filler cap and check for any leaks on the sump plug. Remove the drain tub and dispose of the oil accordingly.
- When you are confident the oil level is correct and that there are 8.3. no apparent leaks, run the engine for approximately one minute to circulate the oil and refill the oil filter with clean oil. Start the motorcycle in the usual manner. Remember to run the motorcycle outside or with a ventilation system in place. Be careful of the hot engine and exhaust whilst running. If you find any leaks during the running process, turn the motorcycle off immediately. Trace the source and consult troubleshooting advice.
- 8.4. After running for one minute, turn the motorcycle off and leave for three minutes to cool. Check the oil by looking at the oil level window making sure the bike is entirely upright. If the oil level is below the centre of the window, remove the oil filler cap and add more oil until the window is 3/4 filled. Refit the oil filler cap and clean off any residue.
- 8.5. Refit the sump guard by bolting the sump guard plate back on to the sump guard mount. Fit the rubber grommets. Tighten the three 10mm sump guard plate bolts up to 40nm.

## CLEAN AIR FILTER

Gain access to the airbox by removing the airbox side cover. 9.1. Remove the three screws that hold the air filter tube in place. Slide the air filter tube out of the airbox. Remove the air filter from the tube. If you have access to an air compressor with an

airline nozzle, use it to blow the air filter clean. If you do not have a compressor, clean thoroughly in warm water, then leave to dry. Spray the air filter with air filter oil to the directions supplied by the manufacture of the product you are using. Refit the air filter by placing it back over the tube and slide it back into the airbox. Tighten the three screws to secure the air filter tube back into the airbox. Put the airbox cover back on, making sure that the rubber grommets are secured correctly.

#### 10. CHECK SPARK PLUG

- 10.1.
- 10.2. then replace with a new one. 10.3.
- 10.4. makes a click.

#### 11. CHECK BRAKE SYSTEM

- 11.1.
- 11.2. ridging on the brake pads 11.3.
- leaks 11.4.

9.



Remove the spark plug cap. Use a 10mm spark plug socket to remove the spark plug, screwing counter-clockwise. Check the plug tip and side electrode. If they have turned entirely black, it can indicate a problem linked to the spark plug operation. If this is the case, see our troubleshooting advice for guidance.

Using a feeler gauge, check the spark plug gap, which should be 0.7-0.8mm. If you are not happy with the spark plug's condition,

Once you are happy with the spark plug's condition (or have replaced for new), you can refit. Using a 10mm spark plug socket tighten to 25nm. Once torqued to spec, give it a small nip with a ratchet to check that the crush washer is fully seated.

Push the spark plug cap onto the spark plug, making sure it

Visually inspect the brake system, checking the following: Front and rear brake pad: visually check the condition and placement of the brake pads. Replace the pads if the wear indicator groove depth is 2mm or less, or if there is any sign of

Calliper banjo fittings: check the area around the banjo on both front and rear callipers, in particular looking for any brake fluid

Brake line routing and condition: check the front and rear brake lines for any excessive wear. Check thoroughly around the front mudguard bracket area as there can sometimes be excessive wear

## SERVICE INFORMATION - SECOND & THIRD SERVICE (Cont.)

at this point if brake line routing is incorrect.

- Front and rear brake discs: check for any warp, sever pitting or 11.5. uneven wear, checking if the rotors have any thin ridges or dips around the outer edge. Should any ridging feel abnormally deep or high, measure the discs for wear using a vernier. The minimum recommended face thickness is 3mm. Replace brake discs is they are below the recommended thickness, or there is abnormal visible damage.
- Replace any parts where issues or damage are visible. 11.6.

#### CHECK AND ADJUST CLUTCH LEVER 12.

- 12.1. Check the free play of the clutch lever by removing the rubber cover on the clutch perch. Check the free play is at 20-25mm as recommended.
- Adjust using the quick adjuster if necessary: crack off the lock 12.2. ring and turn the adjuster counter-clockwise until you achieve the required amount of free play.
- 12.3. Slide the rubber boot back over the perch, ensuring that the lock ring is tight.

#### CHECK REAR WHEEL AND TYRE 13.

- Jack the rear of the motorcycle up on the ramp using the jack 13.1. point. Spin the wheel looking for any nails or objects that have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- Check the rear tire pressure is at the required 2.2 bar/32 psi. If the 13.2. pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.

#### CHECK AND LUBRICATE CHAIN 14.

- With the wheel jacked in the air, check the tension and lubrication 14.1. of the chain.
- 14.2. Slack off the rear wheel axle to release tension from the chain tensioner block.
- Loosen the lock nut off the adjuster by a few centimetres. Rotate 14.3.

the adjusting bolt using the increment marks on the swingarm as a guide. Ensuring the symmetrical movement of both left and right tensioners, check the chain tension. We recommend moving between 4-5mm. Take this measurement from the swingarm to the bottom of the chain. Tighten the adjuster lock nuts and rear axle nut. Fit the rubber axle nut cap securely.

- To lubricate the chain, spin the wheel and spray the chain 14.4. lube directly onto the chain. Remember to pay attention to the instructions of the product. Make a few passes then wipe the brake disc and tire clean.
- Lower the jack and turn the bike around. Always make sure the 14.5. bike is secured on the ramp when doing this. With the bike in the reverse position on the ramp, jack the front wheel into the air using the jacking point.

## CHECK FRONT WHEEL AND TYRE

15.

16.

- 15.1. With the front wheel jacked up into the air, spin the wheel looking for any nails or objects that may have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- Check the rear tire pressure is at the required 2.2 bar/32 psi. If the 15.2. pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.
- Lower and remove the jack from underneath the motorcycle. 15.3.

## CHECK HEADRACE BEARING

- 16.1. Whilst the front wheel is in the air, check for any looseness or play in the headrace bearings. Turn from side to side, checking for any notching or stiffness, then leave the wheel turned to your preferred direction until it is on the steering stop. Rock the wheel back and forth. If you can feel or hear a knock, then consult our troubleshooting advice guidance. If the bearings are in good condition, you should have a smooth and consistent side to side movement and no knocking from front to rear.
- 16.2. Lower and remove the jack from underneath the motorcycle.

## **DIAGNOSTIC CHECK**

17.1.

17.

#### **FINAL CHECK & CLEAN** 18.

- 18.1.
- 18.2.
- 18.3. and brake pedal. 18.4.
  - penetrating oil.
- 18.5.
- And you're done great work!



Remove the seat and find the diagnostics port. Remove the waterproof cover and plug in the MUTT diagnostic scanner. Follow the on-screen instructions and run an error code test. Consult our P codes troubleshooting booklet for guidance for any error codes shown. Refit the waterproof diagnostics port cover and refit the side panel if the test is clear.

To complete the service, final lubrication and cleaning are required. Lubricate the following parts:

**Rider footpegs:** lubricate with white grease or penetrating oil. Wipe off ALL overspray from the exhaust and brake pedal.

**Passenger footpegs:** lubricate with white grease or penetrating oil as with the rider footpegs. Wipe ALL overspray from the exhaust

Brake pedal pivot bush: lubricate with white grease or

Clean and polish the motorcycle thoroughly before returning it to the customer. We recommended using our MUTT cleaning product range for the best finish possible. Cleaning the bike is also an opportunity to check for any other issues that may need attention. Remember always to use brake cleaner to clean brake discs after using any cleaning products.

18.6. Stamp and sign the service booklet once the service is complete.

## SERVICE INFORMATION - FOURTH & FIFTH SERVICE

## SUMMARY

- PREPARE THE MOTORCYCLE
- 2. CHECK LIGHTING SYSTEMS
- 3. CHECK ELECTRONIC HAND CONTROLS
- TURN OFF THE MOTORCYCLE 4.
- 5. DRAIN OIL
- INSPECT AND CLEAN OIL STRAINER 6.
- REMOVE AND REPLACE OIL FILTER 7.
- 8. REPLACE OIL
- 9. CLEAN AIR FILTER
- CHECK SPARK PLUG 10.
- CHECK BRAKE SYSTEM 11.
- 12. CHECK AND ADJUST CLUTCH LEVER
- 13. CHECK AND LUBRICATE BRAKE HOSES
- CHECK REAR WHEEL AND TYRE 14.
- CHECK AND LUBRICATE CHAIN 15.
- CHECK FRONT WHEEL AND TYRE 16.
- CHECK HEADRACE BEARING 17.
- 18. DIAGNOSTIC CHECK
- FINAL CHECK & CLEAN 19.

#### PREPARE THE MOTORCYCLE 1.

- Place the motorcycle on the ramp and secure safely. 1.1.
- Starting and warming the motorcycle is required to thin the 1.2. engine oil to make it easier to drain. Start the bike in the usual manner; make sure the bike is in neutral, pull in the clutch and make sure the side stand is up.

#### CHECK LIGHTING SYSTEMS 2.

- 2.1. With the bike running check the lighting systems:
- Headlight: Check that the headlight and sidelight bulbs are 2.2. running to their full capacity.
- 2.3. Main beam: Check that the main beam bulb is running at full capacity when switched on. Make sure that this doesn't affect any other headlight bulbs when switched on.
- Front and rear indicators: Check that all four indicators are 2.4. flashing at the correct speed (60-120 FPM) and that none of the bulbs is dim or defective.
- **Rear running light:** Check that the rear day running light is 2.5. continuously running without any intermittent flashes or flickers.
- **2.6.** Brake light and front and rear actuators: Check the rear brake light operation by placing one hand over the rear light cluster and pulling the front brake lever. Do the same again for the rear using your foot to press down the brake pedal.
- 2.7. Number plate light: Place your fingers underneath the light cluster checking for the bright white light.
- 2.8. If any of the above are not working of defective, consult the troubleshooting advice.

#### 3. CHECK ELECTRONIC HAND CONTROLS

- 3.1. With the bike still running, check the electronic hand controls:
- Main beam flash switch: Check if the main beam switches on/ 3.2. off using the yellow button on the LHS switchgear. Do this a few times, releasing the switch to check that the main beam goes off correctly.
- Main beam switch: Switch the main beam switch to the on 3.3. position and check if the main beam is on. Check the main beam indicator light is on.

- 3.4. Horn button: Press the horn button on the LHS switchgear an ensure the horn is triggered and audible.
- Indicator switch and cancelling operation: Confirm the 3.5. indicators operate correctly by sliding the indicator switch from right to left. Click the indicator switch entirely in to check the cancelling operation.
- Kill switch operation: Move the red kill switch to the 'off' position. 3.6. Restart the bike to continue warming the oil.
- TURN OFF THE MOTORCYCLE 4.
- 4.1.

## DRAIN OIL

5.

5.1.

5.2.

- Use a suitable drain tub with a capacity of 1L or above. If the bike has no sump guard, move to step 5.3 Remove the sump guard using a 10mm socket or spanner. Undo the three 10mm bolts securing the sump guard plate in place. Keep these bolts safe. Check the anti-vibration rubber grommets fitted to the sump guard plate. Replace if torn or perished or showing other signs of wear. Worn grommets can cause severe vibration and excessive wear on the sump guard mounting points if they are not replaced. Remove the oil filler cap for better oil flow whilst draining. Ensure that your oil drain tub is directly under the engine. Using a 5.3. 17mm socket with an extension secured on the head of the sump plug, remove the plug by turning counter-clockwise. The sump plug is located on the triangular plate underneath the engine, directly in the middle. CAUTION - The oil will be extremely hot - remove with care. We recommend that you wear heat-resistant rubber gloves during the draining process.
- Clean and check the threads and washer on the sump plug. If there 5.4. is any damage to either the threads or the washer, replace the sump plug. Replace the sump plug washer after a maximum of two oil changes.



After three minutes of run time, turn the motorcycle off. Be careful around the bike once it is warmed up, particularly around the engine and exhaust, as it will now be hot.

## SERVICE INFORMATION - FOURTH & FIFTH SERVICE (Cont.)

- Visually check the oil that is draining, looking for any obvious 5.5. metal particulates. If metal particulates are present, then consult the troubleshooting advice.
- Leave the oil to drain for approximately three minutes. Make sure 5.6. the bike stays in the upright position throughout.
- 5.7. Once the oil has drained completely, refit the sump plug, ensuring that the washer is still fitted correctly. Tighten the sump plug clockwise to 25nm f. DO NOT overtighten the sump plug as there is a risk of stripping internal threads. Always make sure you pay attention to our torque specifications and observe the correct settings.
- 5.8. Clean any oil residue off of the engine using brake cleaner.

#### 6. INSPECT AND CLEAN OIL STRAINER

- Unbolt the strainer cover this is the metal triangle that the oil 6.1. sump plug threads onto. Loosen the bolts and remove being careful not to damage the O-ring.
- Remove the oil strainer and clean off any metal particulates by 6.2. washing thoroughly with brake cleaner. If there are any unusual sized parts of metal, consult the troubleshooting advice.
- Once clean, reinstall the strainer and bolt the cover back on, 6.3. ensuring the O-ring is still in place. Torque the bolts to 25nm in a diagonal pattern.

#### REMOVE AND REPLACE OIL FILTER 7.

- 7.1. It is essential to change the oil filter during the first service. After the break-in process, metal particulates can gather in the oil filter. This is entirely normal and indicates that the engine has bedded in correctly.
- Ensure that your drain tub is still underneath the motorcycle, then 7.2. remove the three oil filter house nuts using a 10mm socket. Once removed, ease the oil filter housing cap away from the crankcase. Ensure you remove the cap carefully and try not to tear or damage the paper gasket or rubber O-ring. If you damage these items during this process, they will need replacement.
- Remove the oil filter by extracting the filter out of the filter 7.3. housing. Inspect the oil filter, looking for any obvious signs of

damage. Remember that it is normal to find metal particles, especially during the first service.

- Fit a new oil filter into the housing, ensuring that the oil filter is in 9.2. 7.4. the correct orientation.
- Refit the oil filter housing, ensuring the correct fitting of the o-ring 7.5. and paper gasket. Tighten the three 10mm nuts to 15nm.

## REPLACE OIL

8.

- Remove the oil filler cap. Place a funnel in the oil fill port. Measure 8.1. out 900MLs of 10w40 semi-synthetic motorcycle oil. Place the oil into the engine slowly, being careful not to spill any oil.
- 8.2. After adding the required amount of oil, replace the oil filler cap and check for any leaks on the sump plug. Remove the drain tub and dispose of the oil accordingly.
- When you are confident the oil level is correct and that there are 8.3. no apparent leaks, run the engine for approximately one minute to circulate the oil and refill the oil filter with clean oil. Start the motorcycle in the usual manner. Remember to run the motorcycle outside or with a ventilation system in place. Be careful of the hot engine and exhaust whilst running. If you find any leaks during the running process, turn the motorcycle off immediately. Trace the source and consult troubleshooting advice.
- 8.4. After running for one minute, turn the motorcycle off and leave for three minutes to cool. Check the oil by looking at the oil level window making sure the bike is entirely upright. If the oil level is below the centre of the window, remove the oil filler cap and add more oil until the window is 3/4 filled. Refit the oil filler cap and clean off any residue.
- 8.5. Refit the sump guard by bolting the sump guard plate back on to the sump guard mount. Fit the rubber grommets. Tighten the three 10mm sump guard plate bolts up to 40nm.

## CLEAN AIR FILTER

Gain access to the airbox by removing the airbox side cover. 9.1. Remove the three screws that hold the air filter tube in place. Slide the air filter tube out of the airbox. Remove the air filter from the tube. If you have access to an air compressor with an

airline nozzle, use it to blow the air filter clean. If you do not have a compressor, clean thoroughly in warm water, then leave to dry. Spray the air filter with air filter oil to the directions supplied by the manufacture of the product you are using. Refit the air filter by placing it back over the tube and slide it back into the airbox. Tighten the three screws to secure the air filter tube back into the airbox. Put the airbox cover back on, making sure that the rubber grommets are secured correctly.

#### 10. CHECK SPARK PLUG

- 10.1.
- 10.2. then replace with a new one. 10.3.
- 10.4. makes a click.

#### 11. CHECK BRAKE SYSTEM

- 11.1.
- 11.2. ridging on the brake pads 11.3.
- leaks 11.4.

9.



Remove the spark plug cap. Use a 10mm spark plug socket to remove the spark plug, screwing counter-clockwise. Check the plug tip and side electrode. If they have turned entirely black, it can indicate a problem linked to the spark plug operation. If this is the case, see our troubleshooting advice for guidance.

Using a feeler gauge, check the spark plug gap, which should be 0.7-0.8mm. If you are not happy with the spark plug's condition,

Once you are happy with the spark plug's condition (or have replaced for new), you can refit. Using a 10mm spark plug socket tighten to 25nm. Once torqued to spec, give it a small nip with a ratchet to check that the crush washer is fully seated.

Push the spark plug cap onto the spark plug, making sure it

Visually inspect the brake system, checking the following: Front and rear brake pad: visually check the condition and placement of the brake pads. Replace the pads if the wear indicator groove depth is 2mm or less, or if there is any sign of

Calliper banjo fittings: check the area around the banjo on both front and rear callipers, in particular looking for any brake fluid

Brake line routing and condition: check the front and rear brake lines for any excessive wear. Check thoroughly around the front mudguard bracket area as there can sometimes be excessive wear

## SERVICE INFORMATION - FOURTH & FIFTH SERVICE (Cont.)

at this point if brake line routing is incorrect.

- Front and rear brake discs: check for any warp, sever pitting or 11.5. uneven wear, checking if the rotors have any thin ridges or dips around the outer edge. Should any ridging feel abnormally deep 15. or high, measure the discs for wear using a vernier. The minimum recommended face thickness is 3mm. Replace brake discs is they are below the recommended thickness, or there is abnormal visible damage.
- Replace any parts where issues or damage are visible. 11.6.

#### CHECK AND ADJUST CLUTCH LEVER 12.

- 12.1. Check the free play of the clutch lever by removing the rubber cover on the clutch perch. Check the free play is at 20-25mm as recommended.
- Adjust using the quick adjuster if necessary: crack off the lock 12.2. ring and turn the adjuster counter-clockwise until you achieve the required amount of free play.
- 12.3. Slide the rubber boot back over the perch, ensuring that the lock ring is tight.

#### CHECK AND LUBRICATE BRAKE HOSES 13.

13.1. Introduce a small amount of synthetic grease at the lever end of any outer brake and gear cable runs. Thread the inner cable in to force the lubricant through the pipe. Wipe off any excess as the inner-wire emerges.

CAUTION: Ensure to use synthetic lubricants, not mineral oil or grease. Mineral products may degrade the outer brake hose or gear cable's plastic lining, impacting effective operation.

#### CHECK REAR WHEEL AND TYRE 14.

- Jack the rear of the motorcycle up on the ramp using the jack 14.1. point. Spin the wheel looking for any nails or objects that have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- Check the rear tire pressure is at the required 2.2 bar/32 psi. If the 14.2. pressure is too low, re-pressurise to the required amount. If the

tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.

## CHECK AND LUBRICATE CHAIN

- 15.1. With the wheel jacked in the air, check the tension and lubrication of the chain.
- 15.2. Slack off the rear wheel axle to release tension from the chain tensioner block.
- Loosen the lock nut off the adjuster by a few centimetres. Rotate 15.3. the adjusting bolt using the increment marks on the swingarm as a guide. Ensuring the symmetrical movement of both left and right tensioners, check the chain tension. We recommend moving between 4-5mm. Take this measurement from the swingarm to the bottom of the chain. Tighten the adjuster lock nuts and rear axle nut. Fit the rubber axle nut cap securely.
- 15.4. To lubricate the chain, spin the wheel and spray the chain lube directly onto the chain. Remember to pay attention to the instructions of the product. Make a few passes then wipe the brake disc and tire clean.
- 15.5. Lower the jack and turn the bike around. Always make sure the bike is secured on the ramp when doing this. With the bike in the reverse position on the ramp, jack the front wheel into the air using the jacking point.

#### CHECK FRONT WHEEL AND TYRE 16.

- With the front wheel jacked up into the air, spin the wheel 16.1. looking for any nails or objects that may have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- Check the rear tire pressure is at the required 2.2 bar/32 psi. If the 16.2. pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.
- Lower and remove the jack from underneath the motorcycle. 16.3.

#### 17. CHECK HEADRACE BEARING

17.1.

17.2.

#### 18. **DIAGNOSTIC CHECK**

18.1.

#### 19. **FINAL CHECK & CLEAN**

- 19.1.
- Rider footpegs: lubricate with white grease or penetrating oil. 19.2. Wipe off ALL overspray from the exhaust and brake pedal.
- **Passenger footpegs:** lubricate with white grease or penetrating 19.3. oil as with the rider footpegs. Wipe ALL overspray from the exhaust and brake pedal.
- Brake pedal pivot bush: lubricate with white grease or 19.4. penetrating oil.
- 19.5. Clean and polish the motorcycle thoroughly before returning it to the customer. We recommended using our MUTT cleaning product range for the best finish possible. Cleaning the bike is also an opportunity to check for any other issues that may need attention. Remember always to use brake cleaner to clean brake discs after using any cleaning products.
- Stamp and sign the service booklet once the service is complete. 19.6. And you're done - great work!



Whilst the front wheel is in the air, check for any looseness or play in the headrace bearings. Turn from side to side, checking for any notching or stiffness, then leave the wheel turned to your preferred direction until it is on the steering stop. Rock the wheel back and forth. If you can feel or hear a knock, then consult our troubleshooting advice guidance. If the bearings are in good condition, you should have a smooth and consistent side to side movement and no knocking from front to rear.

Lower and remove the jack from underneath the motorcycle.

Remove the seat and find the diagnostics port. Remove the waterproof cover and plug in the MUTT diagnostic scanner. Follow the on-screen instructions and run an error code test. Consult our P codes troubleshooting booklet for guidance for any error codes shown. Refit the waterproof diagnostics port cover and refit the side panel if the test is clear.

To complete the service, final lubrication and cleaning are required. Lubricate the following parts:

## SERVICE INFORMATION - SIXTH SERVICE ONWARDS

## SUMMARY

- PREPARE THE MOTORCYCLE
- 2. CHECK LIGHTING SYSTEMS
- 3. CHECK ELECTRONIC HAND CONTROLS
- TURN OFF THE MOTORCYCLE 4.
- DRAIN OIL 5.
- INSPECT AND CLEAN OIL STRAINER 6.
- REMOVE AND REPLACE OIL FILTER 7.
- 8. REPLACE OIL
- 9. CLEAN AIR FILTER
- CHECK SPARK PLUG 10.
- CHECK BRAKE SYSTEM 11.
- 12. CHECK AND ADJUST CLUTCH LEVER
- 13. CHECK AND LUBRICATE BRAKE HOSES
- CHECK REAR WHEEL AND TYRE 14.
- CHECK SWINGARM ROLLER BEARINGS 15.
- CHECK AND LUBRICATE CHAIN 16.
- CHECK FRONT WHEEL AND TYRE 17.
- 18. CHECK HEADRACE BEARING
- CHECK TAPPET, VALVE CLEARANCES AND PERFORM COMPRESSION 19. TEST
- DIAGNOSTIC CHECK 20.
- 21. FINAL CHECK & CLEAN

#### PREPARE THE MOTORCYCLE 1.

- Place the motorcycle on the ramp and secure safely. 1.1.
- Starting and warming the motorcycle is required to thin the 1.2. engine oil to make it easier to drain. Start the bike in the usual manner; make sure the bike is in neutral, pull in the clutch and make sure the side stand is up.

#### CHECK LIGHTING SYSTEMS 2.

- 2.1. With the bike running check the lighting systems:
- Headlight: Check that the headlight and sidelight bulbs are 2.2. running to their full capacity.
- 2.3. Main beam: Check that the main beam bulb is running at full capacity when switched on. Make sure that this doesn't affect any other headlight bulbs when switched on.
- Front and rear indicators: Check that all four indicators are 2.4. flashing at the correct speed (60-120 FPM) and that none of the bulbs is dim or defective.
- **Rear running light:** Check that the rear day running light is 2.5. continuously running without any intermittent flashes or flickers.
- 2.6. Brake light and front and rear actuators: Check the rear brake light operation by placing one hand over the rear light cluster and pulling the front brake lever. Do the same again for the rear using your foot to press down the brake pedal.
- 2.7. Number plate light: Place your fingers underneath the light cluster checking for the bright white light.
- 2.8. If any of the above are not working of defective, consult the troubleshooting advice.

#### 3. CHECK ELECTRONIC HAND CONTROLS

- 3.1. With the bike still running, check the electronic hand controls:
- Main beam flash switch: Check if the main beam switches on/ 3.2. off using the yellow button on the LHS switchgear. Do this a few times, releasing the switch to check that the main beam goes off correctly.
- Main beam switch: Switch the main beam switch to the on 3.3. position and check if the main beam is on. Check the main beam indicator light is on.

- 3.4. Horn button: Press the horn button on the LHS switchgear an ensure the horn is triggered and audible.
- Indicator switch and cancelling operation: Confirm the 3.5. indicators operate correctly by sliding the indicator switch from right to left. Click the indicator switch entirely in to check the cancelling operation.
- Kill switch operation: Move the red kill switch to the 'off' position. 3.6. Restart the bike to continue warming the oil.
- TURN OFF THE MOTORCYCLE 4.
- 4.1.

## DRAIN OIL

5.

5.1.

5.2.

- Use a suitable drain tub with a capacity of 1L or above. If the bike has no sump guard, move to step 5.3 Remove the sump guard using a 10mm socket or spanner. Undo the three 10mm bolts securing the sump guard plate in place. Keep these bolts safe. Check the anti-vibration rubber grommets fitted to the sump guard plate. Replace if torn or perished or showing other signs of wear. Worn grommets can cause severe vibration and excessive wear on the sump guard mounting points if they are not replaced. Remove the oil filler cap for better oil flow whilst draining. Ensure that your oil drain tub is directly under the engine. Using a 5.3. 17mm socket with an extension secured on the head of the sump plug, remove the plug by turning counter-clockwise. The sump plug is located on the triangular plate underneath the engine, directly in the middle. CAUTION - The oil will be extremely hot - remove with care. We recommend that you wear heat-resistant rubber gloves during the draining process.
- Clean and check the threads and washer on the sump plug. If there 5.4. is any damage to either the threads or the washer, replace the sump plug. Replace the sump plug washer after a maximum of two oil changes.



After three minutes of run time, turn the motorcycle off. Be careful around the bike once it is warmed up, particularly around the engine and exhaust, as it will now be hot.

## SERVICE INFORMATION - SIXTH SERVICE ONWARDS (Cont.)

- Visually check the oil that is draining, looking for any obvious 5.5. metal particulates. If metal particulates are present, then consult the troubleshooting advice.
- Leave the oil to drain for approximately three minutes. Make sure 5.6. the bike stays in the upright position throughout.
- 5.7. Once the oil has drained completely, refit the sump plug, ensuring that the washer is still fitted correctly. Tighten the sump plug clockwise to 25nm f. DO NOT overtighten the sump plug as there is a risk of stripping internal threads. Always make sure you pay attention to our torque specifications and observe the correct settings.
- 5.8. Clean any oil residue off of the engine using brake cleaner.

#### 6. INSPECT AND CLEAN OIL STRAINER

- Unbolt the strainer cover this is the metal triangle that the oil 6.1. sump plug threads onto. Loosen the bolts and remove being careful not to damage the O-ring.
- Remove the oil strainer and clean off any metal particulates by 6.2. washing thoroughly with brake cleaner. If there are any unusual sized parts of metal, consult the troubleshooting advice.
- Once clean, reinstall the strainer and bolt the cover back on, 6.3. ensuring the O-ring is still in place. Torque the bolts to 25nm in a diagonal pattern.

#### REMOVE AND REPLACE OIL FILTER 7.

- 7.1. It is essential to change the oil filter during the first service. After the break-in process, metal particulates can gather in the oil filter. This is entirely normal and indicates that the engine has bedded in correctly.
- Ensure that your drain tub is still underneath the motorcycle, then 7.2. remove the three oil filter house nuts using a 10mm socket. Once removed, ease the oil filter housing cap away from the crankcase. Ensure you remove the cap carefully and try not to tear or damage the paper gasket or rubber O-ring. If you damage these items during this process, they will need replacement.
- Remove the oil filter by extracting the filter out of the filter 7.3. housing. Inspect the oil filter, looking for any obvious signs of

damage. Remember that it is normal to find metal particles, especially during the first service.

- Fit a new oil filter into the housing, ensuring that the oil filter is in 9.2. 7.4. the correct orientation.
- Refit the oil filter housing, ensuring the correct fitting of the o-ring 7.5. and paper gasket. Tighten the three 10mm nuts to 15nm.

## REPLACE OIL

8.

- Remove the oil filler cap. Place a funnel in the oil fill port. Measure 8.1. out 900MLs of 10w40 semi-synthetic motorcycle oil. Place the oil into the engine slowly, being careful not to spill any oil.
- 8.2. After adding the required amount of oil, replace the oil filler cap and check for any leaks on the sump plug. Remove the drain tub and dispose of the oil accordingly.
- When you are confident the oil level is correct and that there are 8.3. no apparent leaks, run the engine for approximately one minute to circulate the oil and refill the oil filter with clean oil. Start the motorcycle in the usual manner. Remember to run the motorcycle outside or with a ventilation system in place. Be careful of the hot engine and exhaust whilst running. If you find any leaks during the running process, turn the motorcycle off immediately. Trace the source and consult troubleshooting advice.
- 8.4. After running for one minute, turn the motorcycle off and leave for three minutes to cool. Check the oil by looking at the oil level window making sure the bike is entirely upright. If the oil level is below the centre of the window, remove the oil filler cap and add more oil until the window is 3/4 filled. Refit the oil filler cap and clean off any residue.
- 8.5. Refit the sump guard by bolting the sump guard plate back on to the sump guard mount. Fit the rubber grommets. Tighten the three 10mm sump guard plate bolts up to 40nm.

## CLEAN AIR FILTER

Gain access to the airbox by removing the airbox side cover. 9.1. Remove the three screws that hold the air filter tube in place. Slide the air filter tube out of the airbox. Remove the air filter from the tube. If you have access to an air compressor with an

airline nozzle, use it to blow the air filter clean. If you do not have a compressor, clean thoroughly in warm water, then leave to dry. Spray the air filter with air filter oil to the directions supplied by the manufacture of the product you are using. Refit the air filter by placing it back over the tube and slide it back into the airbox. Tighten the three screws to secure the air filter tube back into the airbox. Put the airbox cover back on, making sure that the rubber grommets are secured correctly.

#### 10. CHECK SPARK PLUG

- 10.1.
- 10.2. then replace with a new one. 10.3.
- 10.4. makes a click.

#### 11. CHECK BRAKE SYSTEM

- 11.1.
- 11.2. ridging on the brake pads 11.3.
- leaks 11.4.

9.



Remove the spark plug cap. Use a 10mm spark plug socket to remove the spark plug, screwing counter-clockwise. Check the plug tip and side electrode. If they have turned entirely black, it can indicate a problem linked to the spark plug operation. If this is the case, see our troubleshooting advice for guidance.

Using a feeler gauge, check the spark plug gap, which should be 0.7-0.8mm. If you are not happy with the spark plug's condition,

Once you are happy with the spark plug's condition (or have replaced for new), you can refit. Using a 10mm spark plug socket tighten to 25nm. Once torqued to spec, give it a small nip with a ratchet to check that the crush washer is fully seated.

Push the spark plug cap onto the spark plug, making sure it

Visually inspect the brake system, checking the following: Front and rear brake pad: visually check the condition and placement of the brake pads. Replace the pads if the wear indicator groove depth is 2mm or less, or if there is any sign of

Calliper banjo fittings: check the area around the banjo on both front and rear callipers, in particular looking for any brake fluid

Brake line routing and condition: check the front and rear brake lines for any excessive wear. Check thoroughly around the front mudguard bracket area as there can sometimes be excessive wear

## SERVICE INFORMATION - SIXTH SERVICE ONWARDS (Cont.)

at this point if brake line routing is incorrect.

- Front and rear brake discs: check for any warp, sever pitting or 11.5. uneven wear, checking if the rotors have any thin ridges or dips around the outer edge. Should any ridging feel abnormally deep 15. or high, measure the discs for wear using a vernier. The minimum recommended face thickness is 3mm. Replace brake discs is they are below the recommended thickness, or there is abnormal visible damage.
- Replace any parts where issues or damage are visible. 11.6.

#### CHECK AND ADJUST CLUTCH LEVER 12.

- 12.1. Check the free play of the clutch lever by removing the rubber cover on the clutch perch. Check the free play is at 20-25mm as recommended.
- Adjust using the quick adjuster if necessary: crack off the lock 12.2. ring and turn the adjuster counter-clockwise until you achieve the required amount of free play.
- 12.3. Slide the rubber boot back over the perch, ensuring that the lock ring is tight.

#### CHECK AND LUBRICATE BRAKE HOSES 13.

13.1. Introduce a small amount of synthetic grease at the lever end of any outer brake and gear cable runs. Thread the inner cable in to force the lubricant through the pipe. Wipe off any excess as the inner-wire emerges.

CAUTION: Ensure to use synthetic lubricants, not mineral oil or grease. Mineral products may degrade the outer brake hose or gear cable's plastic lining, impacting effective operation.

#### CHECK REAR WHEEL AND TYRE 14.

- Jack the rear of the motorcycle up on the ramp using the jack 14.1. point. Spin the wheel looking for any nails or objects that have penetrated the tire wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or sidewall bulges.
- Check the rear tire pressure is at the required 2.2 bar/32 psi. If the 14.2. pressure is too low, re-pressurise to the required amount. If the

tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.

## CHECK SWINGARM ROLLER BEARINGS

- 15.1. Jack the rear of the motorcycle up enough that the rear wheel has cleared the ramp surface. Rock the swingarm. Follow our troubleshooting advice if you feel any free play or excessive movement.
- Test the lateral play by gently lifting the rear wheel using a pry bar. 15.2. If you feel excessive movement or free play this can be a sign of failed swingarm bearings or failed shock bushings. Check and replace the bearings or bushings as required.

#### 16. CHECK AND LUBRICATE CHAIN

- 16.1. With the wheel jacked in the air, check the tension and lubrication of the chain.
- Slack off the rear wheel axle to release tension from the chain 16.2. tensioner block.
- Loosen the lock nut off the adjuster by a few centimetres. Rotate 16.3. the adjusting bolt using the increment marks on the swingarm as a guide. Ensuring the symmetrical movement of both left and right tensioners, check the chain tension. We recommend moving between 4-5mm. Take this measurement from the swingarm to the bottom of the chain. Tighten the adjuster lock nuts and rear axle nut. Fit the rubber axle nut cap securely.
- To lubricate the chain, spin the wheel and spray the chain 16.4. lube directly onto the chain. Remember to pay attention to the instructions of the product. Make a few passes then wipe the brake disc and tire clean.
- Lower the jack and turn the bike around. Always make sure the bike is secured on the ramp when doing this. With the bike in the reverse position on the ramp, jack the front wheel into the air using the jacking point.

#### 17. CHECK FRONT WHEEL AND TYRE

With the front wheel jacked up into the air, spin the wheel looking for any nails or objects that may have penetrated the tire sidewall bulges.

17.3.

18.1.

18.2.

19.

19.1.

#### 18. CHECK HEADRACE BEARING

- COMPRESSION TEST
- 19.2.

16.5.

17.1.



wall. While spinning the wheel, check the tire tread and shape condition, looking out for any delamination, odd wear patterns, or

17.2. Check the rear tire pressure is at the required 2.2 bar/32 psi. If the pressure is too low, re-pressurise to the required amount. If the tire pressure has dropped dramatically, carry out a puncture test. Consult troubleshooting advice for guidance.

Lower and remove the jack from underneath the motorcycle.

Whilst the front wheel is in the air, check for any looseness or play in the headrace bearings. Turn from side to side, checking for any notching or stiffness, then leave the wheel turned to your preferred direction until it is on the steering stop. Rock the wheel back and forth. If you can feel or hear a knock, then consult our troubleshooting advice guidance. If the bearings are in good condition, you should have a smooth and consistent side to side movement and no knocking from front to rear.

Lower and remove the jack from underneath the motorcycle.

## CHECK TAPPET, VALVE CLEARANCES AND PERFORM

**CAUTION:** PLEASE ENSURE YOU HAVE THE CORRECT TOOLS AND KNOWLEDGE BEFORE CARRYING OUT THIS PROCEDURE.

Excessive valve clearance may result in excessive valve noise, valve damage and reduced power. Firstly remove the spark plug, and valve inspection caps. Then, remove the generator cover cap and rotate the generator rotor counter-clockwise to align the line on the rotor with the centre arrow mark of the hole on the crankcase to set the piston Top Dead Centre (TDC) on the compression stroke. Check by looking inside the spark plug hole to see if the piston is in the TDC position.

IMPORTANT: Check valve clearance only when the engine is cold. Check and adjust both the intake and exhaust valve when the piston is at TDC of the compression stroke.

19.3. To check valve clearances, remove the tappet cover inspection

## SERVICE INFORMATION - SIXTH SERVICE ONWARDS (Cont.)

ports. Make sure that both valves are loose and are not under tension from the camshaft. Then, insert the thickness feeler gauges to the valve stem end and the adjusting screw on the rocker arm. If the clearance is off the specification, bring it into the specified range, shown below.

ENGINE	IN	EX
125cc	0.08 - 0.13mm	0.08 - 0.13mm
250cc	0.05mm - 0.07mm	0.09mm - 0.11mm

19.4. Perform a compression test to determine whether the engine is generating adequate pressure needed for combustion. Fit the compression tester to a cylinder as per the instructions of your tool. We recommend using a dab of grease or Vaseline to lubricate the threads and O-ring on the adapter to help prolong O-ring life and give a more precise reading. Hold the throttle completely open then using the starter button, turn the motorcycle over until the needle stops climbing the gauge, usually after 3-4 rotations. Record the result and compare to the specifications provided.

## 20. DIAGNOSTIC CHECK

20.1. Remove the seat and find the diagnostics port. Remove the waterproof cover and plug in the MUTT diagnostic scanner. Follow the on-screen instructions and run an error code test. Consult our P codes troubleshooting booklet for guidance for any error codes shown. Refit the waterproof diagnostics port cover and refit the side panel if the test is clear.

### 21. FINAL CHECK & CLEAN

- 21.1. To complete the service, final lubrication and cleaning are required. Lubricate the following parts:
- 21.2. **Rider footpegs:** lubricate with white grease or penetrating oil. Wipe off ALL overspray from the exhaust and brake pedal.
- 21.3. Passenger footpegs: lubricate with white grease or penetrating

oil as with the rider footpegs. Wipe ALL overspray from the exhaust and brake pedal.

- 21.4. Brake pedal pivot bush: lubricate with white grease or penetrating oil.
- 21.5. Clean and polish the motorcycle thoroughly before returning it to the customer. We recommended using our MUTT cleaning product range for the best finish possible. Cleaning the bike is also an opportunity to check for any other issues that may need attention. Remember always to use brake cleaner to clean brake discs after using any cleaning products.
- 21.6. Stamp and sign the service booklet once the service is complete. And you're done - great work!



## **TROUBLESHOOTING - GENERAL INFORMATION**

## General maintenance tools and instruments

The following tools are required for diagnosis and checking purposes.

- Multimeter
- Fuel pressure gauge
- MUTT diagnostic scanner

### **Replacement parts**

Always use MUTT specific parts for any maintenance or replacement; otherwise, we cannot guarantee the correct operation of the EFI system.

## General EFI system maintenance information

Only a suitably qualified and trained technician should undertake disassembly or removal of EFI system components.

During maintenance, ensure gentle handling of electronic components (the ECU, sensors, etc.) to prevent damage.

Disconnecting and connecting wiring plugs or the ECU while the engine is on or running can cause significant, irreparable damage to components. Always ensure that the bike is off before disconnecting or reconnecting electronic components.

Even while the engine is off, fuel in the system is still pressurised. Due to fuel being under high pressure in the fuel pipe, do not undertake the fuel pipe's disassembly during routine maintenance. If work on the fuel system is necessary, ensure pressure release before any fuel pipe disassembly.

To release fuel pressure, remove the fuel pump relay (or remove the fuel pump plug), start the engine and idle until it stops. After completing maintenance, to bring the fuel back to the correct pressure, switch the ignition on and leave for a short while. Only suitably qualified, trained technicians should conduct disassembly and replacement of the fuel pipe in a well-ventilated area, away from any equipment that may ignite fuel or fuel vapour.

Never operate the fuel pump without fuel, as it will lead to significant damage, including burnout. Always ensure correct connection of positive and negative electrical connections to the fuel pump. Failure to do so will lead to damage.

When removing the fuel pump from the fuel tank, first disconnect the wiring plug to ensure that electrical current cannot ignite fuel.

When inspecting the ignition system, spark plug testing should be conducted **only** if necessary and should be as short as possible. Do not open the throttle valve during testing; otherwise, a large amount of unburned fuel will enter exhaust pipe, damaging the catalytic converter.

If a spark test is required, disconnect the wiring plug for the fuel injector.

Manual regulation of idling is unnecessary, as the EFI system manages this. Note the limit screw for the throttle is set during manufacture, and therefore should not be adjusted in any way.

Ensure complete disconnection of the battery and the ECU before undertaking any welding work on the bike.

## ELECTRONIC FUEL INJECTION (EFI) SYSTEM

# **Temperature sensor**

### Oxygen sensor

The oxygen sensor sends measurements of the amount of oxygen flowing into the intake. The sensor outputs a voltage to the ECU, which adjusts the fuel-to-air ratio for correct performance. Voltage decreases when oxygen concentration is high and increases when oxygen concentration is low.

## Rotation speed sensor (trigger coil, crank position)

The rotation speed sensor generates and sends an ignition signal to the ECU; according to the signal, the ECU calculates and determines injection and ignition time. There is an installation clearance requirement of between 0.4 to 0.9 mm.

## Fuel pump assembly

The fuel pump assembly, which sits in the fuel tank, consists of the fuel pump, the pressure regulating valve, and the fuel pump support. By controlling the power supply, the ECU manages the fuel pump action to provide the fuel injector with fuel at high pressure. The pressure regulating valve regulates the fuel pressure from the pump at 2.5MPa, ensuring delivery to the fuel injector at a stable pressure.

## **Fuel injector**

The fuel injector delivers fuel from the fuel pump via gravity and injects pressurized fuel into the air inlet pipe.

The ECU controls the pressure piston, managing delivery of the necessary amount of fuel at optimal timing during engine operation.



The temperature sensor provides the engine with a temperature signal to ensure correct ignition angle and fuel injection quantity during startup, idling and normal operation. When the engine temperature is low, the sensor ensures that the fuel quantity increases.

## **TROUBLESHOOTING - FAULT DIAGNOSIS - GENERAL**

## ENGINE START FAILURE

Before checking the EFI system, first check for other common issues that may prevent engine start:

- Check if the fuel tank is filled with fuel (but is not overfilled)
- Check that the battery is properly charged
- Check if the main fuse (behind right side panel next to the battery) needs replacing
- Check that the starter works when you press the starter button (spark test)

If excessive fuel has been added to the fuel tank, follow the steps outlined below. Ensure the bike is in neutral before conducting.

- Switch on the ignition and allow the fuel pump to prime.
- Keep the throttle fully opened and press the electric start simultaneously for 5 seconds to remove excess fuel.

If all of the above checks show no issues, investigation of the EFI system is required. Engine start failure is generally caused by faults with the following parts:

Failure of the following parts will result in the engine operating using standard ECU preset operating values:

Air temperature (pressure) sensor	Throttle position sensor	Cylinder wall temperature sensor	Oxygen sensor
---	--------------------------	--	---------------

Undertake initial diagnosis using the fault indicator light or a MUTT diagnostic scanner. Check fault codes against the fault code table, and perform the required test to check parts, following the disassembly and testing requirements outlined.

If after checking the fault indicator light or diagnostic scanner, no fault can be identified, conduct a fault diagnosis using the steps in the table.

Fault	Possible Cause	Check	Fix	
Engine does not start, or starts and immediately cuts out - no fuel from fuel pump.	No fuel	Open ignition switch and check fuel level gauge, or check the fuel level in the tank	Refuel	
	Faulty/damaged fuel pump	Check fuel pump	Replace fuel pump	
	No voltage to fuel pump	Check fuse and power relay	Replace damaged parts	
	Poor contact on fuel pump plug	Check the fuel pump plug contact	Ensure correct contact	
Engine does not start, or starts and immediately cuts out - fuel pump and ignition are working	Low fuel pressure and low ignition voltage caused by low battery charge	Use a multimeter to measure the battery voltage	Charge or replace battery	
	Excess carbon build up or incorrect clearance of the spark plug	Remove and check spark plug for carbon deposits, and check clearance	Clean spark plug and adjust to correct clearance	
	Fuel leak causes low fuel pressure	Check fuel pipe for leaks	Replace the fuel pipe, or tighten the fuel pipe clamp	
Unstable idling	Low fuel pressure	Check fuel pressure using fuel pressure gauge connected between the fuel pump and the fuel injector	Check for issues that may be causing low fuel pressure	
	Air leak at air idle sensor/motor	Spray with leak test liquid while the engine is running	Check and tighten the step motor	
	Leak at valve and flange assembly	Spray with leak test liquid while the engine is running	Check and repair assembly	
Excessively high idling	Step motor is stuck	Check stepping motor for debris or fault	Remove debris or replace	
Insufficient power	Low fuel pressure	Check fuel pressure using fuel pressure gauge connected between the fuel pump and the fuel injector	Check for issues that may be causing low fuel pressure	

ð	MUTT Motorcycles
Ŭ	Motorcycles

## TROUBLESHOOTING - FALLET DIAGNOSIS - FALLET CODES

TROUBL	<b>MUTT</b> Motorcycles						
Fault/Flash Code	Part Name	Part Code	Fault Description	Check	Fault Indication	Parameters	Verification Test
P0107	MANIFOLD ABSOLUTE PRESSURE SENSOR		Sensor voltage input low	Check the voltage input	Voltage is lower than expected		30 seconds after ignition on
P0108	MANIFOLD ABSOLUTE PRESSURE SENSOR		Sensor voltage input high	Check the voltage input	Voltage is higher than expected		30 seconds after ignition on
P0112	AIR TEMPERATURE (PRESSURE) SENSOR	MPT-0341	Sensor voltage input low	Check the voltage input	Voltage is lower than expected	4.75V ~ 5.25V	30 seconds after ignition on
P0113	AIR TEMPERATURE (PRESSURE) SENSOR	MPT-0341	Sensor voltage input high	Check the voltage input	Voltage is higher than expected	4.75V ~ 5.25V	30 seconds after ignition on
P0117	CYLINDER WALL TEMPERATURE SENSOR	MPT-0181	Sensor voltage input low	Check the voltage input	Voltage is lower than expected		30 seconds after ignition on
P0118	CYLINDER WALL TEMPERATURE SENSOR	MPT-0181	Sensor voltage input high	Check the voltage input	Voltage is higher than expected		30 seconds after ignition on
P0122	THROTTLE POSITION SENSOR	MPT-0342	Sensor voltage input low	Check the voltage input	Voltage is lower than expected	4.75V ~ 5.25V	30 seconds after ignition on
P0123	THROTTLE POSITION SENSOR	MPT-0342	Sensor voltage input high	Check the voltage input	Voltage is higher than expected	4.75V ~ 5.25V	30 seconds after ignition on
P0131	OXYGEN SENSOR	MPT-0180	Sensor voltage input low	Check the voltage input	Voltage is lower than expected	12V ~ 16V	Idle for 5 mins
P0132	OXYGEN SENSOR	MPT-0180	Sensor voltage input high	Check the voltage input	Voltage is higher than expected	12V ~ 16V	Idle for 5 mins
P0031	OXYGEN SENSOR (HEATER)	MPT-0180	Sensor voltage input low	Check the voltage input	Voltage is lower than expected	12V ~ 16V	30 seconds after ignition on
P0032	OXYGEN SENSOR (HEATER)	MPT-0180	Sensor voltage input high	Check the voltage input	Voltage is higher than expected	12V ~ 16V	Idle for 5 mins
P0201	FUEL INJECTOR	MPT-0480	Fuel injector circuit open	Measure the resistance be- tween the fuel injector plug pins	Incorrect resistance	12.6Ω ~ 11.4Ω	Press the start button for 5 seconds
P0232	FUEL PUMP RELAY	MPT-0307	High voltage input	Check the voltage input	Voltage is higher than expected	approx. 12V	30 seconds after ignition on
P0337	CRANKSHAFT POSITION SENSOR		Low voltage output	Check the voltage output	Voltage is lower than expected		Press the start button for 5 seconds
P0351	IGNITION COIL	MPT-0297 / MPT-0296	Incomplete circuit				30 seconds after ignition on
P0505	AIR IDLE SENSOR (IDLE STEP MOTOR)	MPT-0343	Idle control fault				Idle for 5 mins

## DIAGNOSIS AND TROUBLESHOOTING WITH A FAULT CODE

Faults are generally caused by one of four main problems:

- Plugs not plugged in correctly
- Damage to connecting wires
- Poor contact from corroded plugs.
- Individual components are damaged or non-operational.
- The ECU is damaged or operating incorrectly. •

The main methods for addressing these faults are:

- · Check all plugs and wires for loose connections, damage, or incorrect fitting.
- Check individual components for faults.
- Check the ECU is operating correctly.

Before undertaking any of individual component checks, it is essential to ensure the primary wiring system is fitted correctly, is not damaged, and operates normally.

For individual component checks, refer to the disassembly, testing and reassembly information on the pages following

## **OXYGEN SENSOR**

#### Disassembly

Disconnect the wiring plug, and remove the oxygen sensor

### Testing

## Check the resistance of the oxygen sensor heating rod:

- Ensure the ignition is off and unplug the oxygen sensor
- Measure the resistance between pin C and D of the oxygen sensor
- Resistance should be between  $8\Omega$  and  $15\Omega$  at  $23^{\circ}$ c

If the heating rod resistance of the oxygen sensor is correct, proceed to check the heating voltage. If not, replace the oxygen sensor.

### Check the heating voltage of the oxygen sensor:

- Ensure the ignition is off and unplug the oxygen sensor
- Start the engine and keep the bike idling.
- After waiting for 20 seconds, use a multimeter to measure the voltage of the pins on the wiring loom
- The voltage should read between 12V to 16V

If the heating voltage is correct, check the output signal voltage. If not, check for wiring loom damage and if necessary, replace.

## Check output signal voltage of the oxygen sensor:

- Ensure the ignition is off and the oxygen sensor plug is connected
- Start the engine and keep the bike idling, heating the engine until the cylinder head reaches a temperature of around 60°c
- Switch your multimeter to DC voltage; contact black and red probes with pin A and B of the oxygen sensor separately
- Check the change in voltage the output voltage should change between 0 and 1V.

If the heating voltage is correct, check for wiring loom damage and if necessary, replace. If the reading is incorrect, then replace the oxygen sensor.

### **OXYGEN SENSOR**

#### Assembly

- Torque to 13Nm 17Nm
- Reconnect the wiring plug



Screw the oxygen sensor into the threaded hole

NOTES: The bend angle of the wires should not be less than R20. Do not disassemble or assemble the sensor after connecting to the main loom

### AIR TEMPERATURE (PRESSURE) SENSOR

#### Disassembly

Disconnect the wiring plug, and remove the air temperature (pressure) sensor.

#### Testing

### Check the input voltage of the air temperature pressure sensor:

- Ensure the ignition is off and unplug the sensor
- Turn on the ignition, but without starting the engine.
- Measure the voltage at the plug pins
- Input voltage should be between 4.75V to 5.25V

If the voltage reads correctly, this indicates that the ECU's power supply is normal and that sensor replacement is required. If the reading is incorrect, then check the main wiring loom for issues

#### Check the resistance of the air temperature pressure sensor:

- Ensure the ignition is off and unplug the sensor
- Measure the resistance between the plug pins using a multimeter
- Expected resistance should be as follows:

Temperature (°c)	Resistance (KΩ)
-10	8.11 ~ 9.71
0	5.21 ~ 6.04
20	2.32 ~ 2.54
40	1.10 ~ 1.21

If the resistance is between expected levels, the sensor is operating correctly; check the wiring loom for issues. If the resistance is incorrect, replace the sensor.

Assembly

MUTT

Plug and remount the sensor

### THROTTLE POSITION SENSOR

### Disassembly (Throttle Valve)

Disconnect the wiring plug, and remove the throttle position sensor

#### Testing

### Check the input voltage of the throttle position sensor:

- Turn the ignition on;
- Measure the voltage between the connecting pins on the main wiring loom.
- The voltage should be between 4.75V to 5.25V

If the voltage reads correctly, this indicates that the ECU's power supply is normal and that sensor replacement is required. If the reading is incorrect, then check the main wiring loom for issues

#### Assembly

Plug and remount the sensor.

IMPORTANT: Only a suitably trained and qualified technician should replace the throttle position sensor.

### CYLINDER WALL TEMPERATURE SENSOR

#### Disassembly

sensor

#### Testing

## Check the resistance of the cylinder wall temperature sensor:

- Measure the resistance of the plug pins

If the voltage reads correctly, this indicates that the ECU's power supply is normal and that sensor replacement is required. If the reading is incorrect, then check the main wiring loom for issues

## Temperatur

-10

0

20

40

replace the sensor.

Assembly

Plug and remount the sensor

MOTORCYCLES TECHNICAL MANUAL - MUTT MOTORCYCLES 125CC EU5 M1 (MONOSHOCK VARIANTS) - V2.0/E2 08/21	© Mutt Motorcycles Ltd. 2021 NOT FOR UNAUTHORISED DISTRIBUTION	



Disconnect the wiring plug, and remove the cylinder wall temperature

- Ensure the ignition is off and unplug the sensor
- Expected resistance should be as follows:

re (°c)	Resistance (KΩ)
	58.1 ~ 68.28
	33.15 ~ 38.29
	11.99 ~ 13.43
	4.89 ~ 5.33

If the resistance is at normal levels, this indicates that the sensor is operating correctly. Check the wiring loom for any issues. If the resistance is incorrect,

### **FUEL INJECTOR**

#### Disassembly

- Disassemble the fuel inlet pipe.
- Disconnect the wiring plug.
- Remove the 2x holding and 2x fixing pins.
- Slowly screw out the fuel injector.

### Testing

### Check resistance of fuel injector coil:

- Ensure the ignition is off and unplug the sensor
- Measure the resistance between the fuel injector plug pins using a multimeter
- The resistance should be between  $12.6\Omega \sim 11.4\Omega$

If the resistance is between expected levels, check the main wiring loom for any issues. If not, replace the fuel injector.

#### Assembly

#### Preparation before assembly:

- Do not use the fuel injector if it has been dropped or knocked, as this could lead to damage to the internal components, which will lead to poor performance and other possible issues.
- Check the O-ring and seal are free from damage.
- Always replace the O-ring when reassembling the fuel injector. Sparingly apply a thin layer of paraffin-based mineral oil to the O-ring and the locating surfaces.

#### Specific assembly steps:

- Align the fuel injector with the air inlet elbow's corresponding position and carefully screw it into the installation hole.
- After inserting the screw into the installation hole and re-installing the fixing, screw the fuel injector into the air inlet pipe's installation hole, using a torque setting of 6 to 10Nm.

### **FUEL INJECTOR**

#### Assembly

#### NOTES:

- Be cautious when disassembling or assembling wiring plugs to avoid damage.
- Always assemble or disassemble the fuel injector gently, ensuring surfaces are clean and free of debris.
- Do not use a 12V supply to directly energize the fuel injector for more than 60 seconds, as this will damage the fuel injector.
- Never run the fuel injector without fuel.

IMPORTANT: Fuel injector removal, inspection and replacement should be undertaken by a trained, qualified technician.

#### FUEL PUMP ASSEMBLY

#### Disassembly

- Disconnect the wiring plug

#### Testing

### Check fuel pump voltage:

- Switch the ignition on
- The voltage should read around 12V.

the next step.

#### Check fuel pump lines:

- Ensure the ignition is off
- connected.

	Inspection Point	Connected	Not Connected
а	Fuel pump relay A pin-ECU_J2-9 pin	Circuit is connected. Change the current ECU for one that is known to be correctly operational to check	Fuel pump relay circuit open
b	Fuel pump relay B pin-fuel pump A pin		Fuel pump power circuit open
с	Negative pole of power-fuel pump B pin	again.	Fuel pump earth circuit open
(continues on next page)			



Disassemble the fuel pipe that connects to the fuel outlet pipe

Remove the 6x holding bolts, then remove the fuel pump

Ensure the ignition is off and unplug the fuel injector

Measure the voltage supply to the fuel pump at the main wiring loom, ensuring to do this within 3 seconds after turning on the ignition.

If the voltage is standard, then replace the fuel pump. If not, then proceed to

• Pull out the ECU plug, turn the ignition on and within 3 seconds after turning the ignition on check whether the wiring loom's corresponding pins are

### FUEL PUMP ASSEMBLY

Turn off the engine and reconnect the plug. Turn the ignition back on and check for connection based on the following:

	Inspection Point	Voltage is 12V	Voltage is <b>not</b> 12V
d	Fuel pump relay B pin-positive pole of power	Fuel pump has rotation sound	Fuel pump relay +12V - fuel pump relay circuit open. Replace fuel pump relay.
е	Fuel pump A(+)B(-)and power voltage		Fuel pump power +12V Fuel pump circuit open. Replace fuel pump.

IMPORTANT: Do not run the fuel pump assembly without fuel.

#### Assembly

- Bolt into place using the 6x bolts (torque settings 2.2Nm to 2.8Nm)
- Reconnect the wiring plug
- Re-attach the fuel pipe to the fuel outlet pipe

NOTES: Ensure the locking device is released sufficiently before removing the plug. Hold the plug-in instead of holding the wires. Do not exert excessive force, as this could lead to wire and component damage.

## AIR IDLE SENSOR (IDLE STEP MOTOR)

#### Disassembly

Disconnect the wiring plug, and remove the sensor

#### Testing

#### Check the resistance of the air idle sensor coil:

- Measure the resistance of the sensor pins using a multimeter:
- Resistance should be between 53±5.3Ωfrom 5°c to 27°c

If the resistance is correct, check the main wiring loom for issues. If not, replace the sensor.

#### Assembly

Plug and remount the sensor

NOTES: When changing this component, do not pull or push it on to the fitting shaft manually, as this will damage the actuator.

IMPORTANT: Do not remove or refit the idle step motor when the power is on.

#### THROTTLE VALVE

#### Disassembly

- screwdriver.
- Disconnect the wiring plug

#### Assembly

### NOTES:

- Do not let the throttle valve open and close suddenly as this can damage • the throttle valve and its main body.
- throttle valve.
- Do not use compressed air.
- Take care that no debris or moisture enters the throttle valve access when fitting or replacing the throttle valve.
- the wiring pin



Loosen the accelerator cable locking nut using a 10mm open spanner. Take the lower end of the accelerator cable out of the throttle valve slot, then take the accelerator cable's interior wire out of the throttle valve slot. Remove the connecting sleeve clamp of the air inlet elbow using a

Never adjust the idling regulating screws. Only a suitably trained, qualified technician should undertake any maintenance on the throttle valve.

To reassemble the throttle valve, reverse the disassembly procedure.

- Do not disassemble the throttle valve and its idling regulating bolt.
- Do not apply carburettor cleaner to the main body components of the

- Do not adjust the stop screw of the throttle valve
- · The plug should be removed and replaced carefully to prevent damage of

#### AIR INLET ELBOW

### Disassembly

- Remove connecting sleeve clamp using a screwdriver.
- Disconnect the wiring plug
- Disassemble the holding nut and bolt, and then remove

### Assembly

- Install the air inlet pipe by reversing the disassembly sequence.
- Torque for the holding nut and bolt is between 6Nm to 10Nm.

sassembly	Item			
		Specificati	on	Parameters
Close ignition switch Remove the ECU		Storage ter	nperature (°c)	-40 ~ 105
Disconnect wiring plug	ECU	Working te	Working temperature (°c) Working voltage (V/DC)	
sembly		Working vo		
Before installation, confirm the plug and ECU slot are free of dust, dirt,		-10°c	κΩ	58.10 ~ 68.28
water, or other debris. Gently push the ECU towards the plug. The plug should click into place		0°c	κΩ	33.15 ~ 8.29
fully.	CYLINDER WALL	20°c	κΩ	11.99 ~ 13.43
IMPORTANT: Ensure that the engine is not running/on before removing the       TEMPERATURE SENSOR         ECU. DO NOT DISASSEMBLE THE ECU WHILE THE IGNITION IS ON.       .         .	40°c	κΩ	4.89 ~ 5.33	
		Working temperature (°c)		-40 ~ 200
		Tightening	torque (Nm)	12±2
		Working voltage (V/DC)		12 ~ 14
	OXYGEN SENSOR	Heating rod resistance (Ω @ 23°c)		8 ~ 15
		Tightening torque (Nm)		13 ~ 17
		Working temperature (°c)		-30 ~ 130
	FUEL INJECTOR	Working voltage (V/DC)		14
		Working medium pressure (KPa)		<500
	AIR IDLE SENSOR (IDLE STEP MOTOR)	Resistance Ω (5°c ~ 27 °c)		53±5.3

MUTT Motorcycles
ð

hmi

